

SFRA User Guide

This User Guide provides specific guidance for the SFRA and should be used by all involved in the development planning process. This Guide contains four key chapters comprising:

- Guidance for Development Plan Documents
- Guidance for Development Management
- Guidance for Developers
- Guidance for Flood Risk Management

SFRA Mapping

A suite of strategic flood risk maps have been produced for the SFRA. These maps should be used to locate development away from areas at high risk of flooding.

Future development planning also needs to make reference to this suite of strategic flood risk maps, as well as any updated information provided by the LPA and Environment Agency.

Use of SFRA Data

Whilst all data used in the preparation of this SFRA has been supplied to the LPA (including reports, mapping, GIS datasets and development allocation assessments) there is a need to maintain controls over the data and how it is applied and modified. It is anticipated that the SFRA and associated maps will be published on the Council's website as a set of interactive GeoPDFs. As the central source of SFRA data, these maps should be made available for download.

The LPA will be able to use the flood outlines and flood risk data used in this SFRA for internal use. The use of this information must consider the context within which it was produced. The use of this data will fall under the license agreement between the LPA and the Environment Agency as it has been produced using Environment Agency data. It should be remembered that more detailed FRAs, where required, should seek to refine the understanding of flood risk from all sources to any particular site.

SFRA data should not be passed on to third parties outside of the LPA. Any third party wishing to use existing Environment Agency flood risk datasets should contact the Environment Agency External Relations department. A charge is likely to apply for the use of this data.

Contents

Contents	2
1 Guidance for Development Plan Documents	10
1.1 Introduction	10
1.2 Sequential Test.....	11
1.3 Exception Test.....	12
1.4 Applying the Sequential Test and assessing the likelihood of passing the Exception Test.....	13
1.5 Flood Risk and other Land Use Policies.....	15
2 Guidance for Development Management.....	17
2.1 Introduction	18
2.2 The Sequential Test and Exception Test.....	18
2.3 Supporting the FRA Process	19
3 Guidance for Developers	21
3.1 Introduction	21
3.2 The Sequential Test and Exception Test.....	22
3.3 Site specific Flood Risk Assessments	22
3.4 FRA Guidance	25
3.5 Critical Drainage Areas.....	27
3.6 Considering risk of flooding from other sources	27
4 Guidance for Flood Risk Management.....	32
4.1 Introduction	32
4.2 Strategic Approach	32
4.3 Potential mitigation measures	32
Appendices.....	I
A. Flood Risk Concepts	I
B. Stakeholder Engagement and Data Management	XI
C. Flood Risk Vulnerability Classification	XIII
D. Sustainable Drainage Systems	XV
E. Flood Risk Mitigation	XX

List of Figures

Figure 1-A: First and Second Pass of Proposed Development Sites Sequential Test.....	14
Figure 1-B: Identifying the Likelihood of Passing the Exception Test	15
Figure 3-A: FRA Preparation	25
Figure A-2 (Source-Pathway-Receptor model).....	VIII
Figure D-2 SuDS Management Train Principle	XV

List of Tables

Table 2-1: FRA considerations and SFRA supporting evidence	19
Table 3-1: Development types and application of Sequential and Exception Tests.....	22
Table 3-2: FRA considerations and SFRA supporting evidence	23
Table A1: Reservoir Consequence Classification.....	IV
Table A2: AIMS Condition Ratings for Flood Defences.....	VI
Table A3: Flood Hazard ratings.....	IX
Table B1: Stakeholder Involvement.....	XI
Table D1: Suitability of SuDS Techniques	XVI

Abbreviations

ABD	Areas Benefiting from Defences
AEP	Annual Exceedance Probability
AIMS	Asset Information Management System
CFMP	Catchment Flood Management Plans
CLG	Communities and Local Government
COW	Critical Ordinary Watercourses
CRR	Community Risk Register
CSO	Combined Sewer Overflow
DPDs	Development Plan Documents
DTM	Digital Terrain Model
EA	Environment Agency
ELA	Employment Land Availability
EU	European Union
FCERM	Flood and Coastal Erosion Risk Management
FRA	Flood Risk Assessment
FRM	Flood Risk Management
LDDs	Local Development Documents
LDF	Local Development Framework
LIDAR	Light Detection and Ranging
LPAs	Local Planning Authorities
NFCDD	National Fluvial and Coastal Defence Database
NPPF	National Planning Policy Framework
PPG	Planning Practice Guidance
RFRA	Regional Flood Risk Assessment
RBMP	River Basin Management Plans
RPB	Regional Planning Bodies
RPG	Regional Planning Guidance
RSS	Regional Spatial Strategy
SA	Sustainability Appraisal
SAB	SuDS Approval Body
SCI	Statement of Community Involvement
SEA	Strategic Environmental Assessment
SFRA	Strategic Flood Risk Assessment
SHLAA	Strategic Housing Land Availability Assessment
SMP	Shoreline Management Plans
SoP	Standard of Protection
SuDS	Sustainable (Urban) Drainage Systems
SWMP	Surface Water Management Plan
UDP	Unitary Development Plan
uFMfSW	updated Flood Map for Surface Water
WCS	Water Cycle Study
WFD	Water Framework Directive
YW	Yorkshire Water

Glossary

Actual risk

The risk posed to development situated within a defended area (i.e. behind defences), is expressed in terms of the probability that the defence will be overtopped, and/or the probability that the defence will suffer structural failure and the consequences should the failure occur.

Annual exceedence probability

The estimated probability of a flood of given magnitude occurring or being exceeded in any year. Expressed as, for example, 1 in 100 chance or 1 per cent Annual Exceedence Probability (AEP).

Adoption of sewers

The transfer of responsibility for the maintenance of a system of sewers to a sewerage undertaker.

Attenuation

Reduction of peak flow and increased duration of a flow event usually by temporary storage of flood water.

Catchment Flood Management Plans (CFMP)

A strategic planning tool through which the Environment Agency seeks to work with other key decision-makers within a river catchment to identify and agree policies for sustainable flood risk management.

Climate change

Long-term variations in global temperatures and weather patterns, as a consequence of both natural causes and as a result of human activity.

Compensation storage

A floodplain area introduced to compensate for the loss of storage as a result of land raising for development purposes.

Design event

A historic or notional flood event of a given annual flood probability, against which the suitability of a proposed development is assessed and mitigation measures, if any, are designed.

Design event exceedence

Flooding resulting from an event which exceeds the magnitude for which the defences protecting a development were designed (see residual risk).

Design flood level

The maximum estimated water level during the design event.

DG5 register

Register held by water companies on the location of properties at risk of flooding from public sewers

Exceedence flow

Excess flow that emerges on the surface once the conveyance capacity of a drainage system is exceeded.

Extreme Flood Outline

Flood 'zone' maps released by the Environment Agency in showing anticipated undefended 0.1% AEP flood extents in a consistent manner throughout the UK.

Flood defence

Flood defence infrastructure, such as flood walls and embankments, intended to protect an area against flooding to a specified standard of protection.

Flood Map

A map produced by the Environment Agency providing an indication of the likelihood of flooding within all areas of England and Wales, assuming there are no flood defences. Only covers flooding from rivers and the sea.

Floodplain

Area of land that borders a watercourse, an estuary or the sea, over which water flows in times of flood, or would flow but for the presence of flood defences where they exist.

Flood Estimation Handbook (FEH)

Provides current methodologies for estimation of flood flows for the UK.

Flood Risk Management (FRM)

The introduction of mitigation measures (or options) to reduce the risk posed to property and life as a result of flooding. It is not just the construction of physical flood defences.

Flood risk management strategy

A long-term approach setting out the objectives and options for managing flood risk, taking into account a broad range of technical, social, environmental and economic issues.

Flood Risk Assessment (FRA)

A study to assess the risk to an area or site from flooding, now and in the future, and to assess the impact that any changes or development on the site will have on flood risk to the site and elsewhere. It may also identify, particularly at more local levels, how to manage those changes to ensure that flood risk is not increased.

Flood risk management measure

Any measure which reduces flood risk such as flood defences.

Flood Zone

A geographic area within which the flood risk is in a particular range, as defined by EA flood mapping.

Fluvial

Flooding caused by overtopping of rivers or stream banks.

Freeboard

The difference between the flood defence level and the design flood level, which includes a safety margin for residual uncertainties.

Greenfield land

Land that has not been previously developed.

ISIS

ISIS is a software package used for 1-Dimensional river modelling. It is used as an analysis tool for flood risk mapping, flood forecasting and other aspects of flood risk management analysis.

Local Plan

Local Plans make strategic provision for the long-term use of land and buildings, providing a framework for local decision making and the reconciliation of competing development and conservation interests.

Main River

A watercourse designated on a statutory map of Main Rivers, maintained by Defra, on which the Environment Agency has permissive powers to construct and maintain flood defences (and powers to manage development).

Major development

A major development is:

- a) Where the number of dwellings to be provided is ten or more, or the site area is greater than 0.5 ha or
- b) Non-residential development, where the floor space to be provided is greater than 1,000 m² or the site area is greater than 1 ha.

National Planning Policy Framework (NPPF)

The National Planning Policy Framework sets out the Government's planning policies for England and how these are expected to be applied. This replaces PPS25.

Ordinary watercourse

All rivers, streams, ditches, drains, cuts, dykes, sluices, sewers (other than public sewer) and passages through which water flows which do not form part of a Main River. Local authorities and, where relevant, Internal Drainage Boards have similar permissive powers on ordinary watercourses, as the Environment Agency has on Main Rivers.

Permitted development rights

Qualified rights to carry out certain limited forms of development without the need to make an application for planning permission, as granted under the terms of the Town and Country Planning (General Permitted Development) Order (2010).

Pound length

The length of a section of canal between locks is referred to as pound length.

Previously developed land

Land which is or was occupied by a permanent structure, including the curtilage of the developed land and any associated fixed surface infrastructure (often referred to as Brownfield land).

Reservoir (large raised)

A reservoir that holds at least 25,000 cubic metres of water above natural ground level, as defined by the Reservoirs Act 1975. The FWMA 2010 updated the Reservoirs Act and targeted a reduction in the capacity at which reservoirs should be regulated from 25,000 cubic metres to 10,000 cubic metres. This reduction is, at the time of writing, yet to be confirmed meaning the requirements of the Reservoirs Act 1975 should still be adhered to.

Residual risk

The risk which remains after all risk avoidance, reduction and mitigation measures have been implemented.

Resilience

Constructing a building in such a way that although flood water may enter the building, its impact is minimised, structural integrity is maintained and repair, drying & cleaning are facilitated.

Resistance

Constructing a building in such a way as to prevent flood water entering the building or damaging its fabric. This has the same meaning as flood proof.

Return period

The long-term average period between events of a given magnitude which have the same annual exceedence probability of occurring.

Risk

The threat to property and life as a result of flooding, expressed as a function of probability (that an event will occur) and consequence (as a result of the event occurring).

Runoff

The flow of water from an area caused by rainfall.

Section 106 Agreement

Section 106 of the Town and Country Planning Act 1990 (as amended) allowing local planning authorities to negotiate arrangements whereby the developer makes some undertaking if he/she obtains planning permission. These are known interchangeably as planning agreements, planning obligations or planning gain.

Section 106 (Water Industry Act 1991)

A key section of the Water Industry Act 1991, relating to the right of connection to a public sewer.

Standard of Protection (SOP)

The design event or standard to which a building, asset or area is protected against flooding, generally expressed as an annual exceedence probability.

Strategic Environmental Assessment (SEA)

European Community Directive (2001/42/EC) which assesses the effects of certain plans and programmes on the environment.

Strategic Flood Risk Assessment (SFRA)

The assessment of flood risk on a catchment-wide basis for proposed development in a Local Planning Authority area. Should be first point of consultation in all development proposals.

Sustainable Drainage Systems (SuDS)

A sequence of management practices and control structures, often referred to as SuDS, designed to drain water in a more sustainable manner than some conventional techniques. Typically these are used to attenuate runoff from development sites and involve infiltration to groundwater wherever feasible.

Sustainability Appraisal (SA)

An integral part of the plan-making process which seeks to appraise the economic, social and environmental effects of a plan in order to inform decision-making that aligns with sustainable development principles.

TUFLOW

TUFLOW is a software package used for 2-Dimensional river modelling. It is used as an analysis tool for flood risk management.

Vulnerability Classes

NPPF (Table 3) provides a vulnerability classification to assess which uses of land maybe appropriate in each flood risk zone.

Washland

An area of the floodplain that is allowed to flood or is deliberately flooded by a river or stream for flood management purposes.

Water Framework Directive (WFD)

A European Community Directive (2000/60/EC) of the European Parliament and Council designed to integrate the way water bodies are managed across Europe. It requires all inland and coastal waters to reach "good status" or "good potential status" by 2015 through a catchment-based system of River Basin Management Plans, incorporating a programme of measures to improve the status of all natural water bodies.

Windfall sites

Sites which become available for development unexpectedly and are therefore not included as allocated land in a planning authority's development plans.

1 Guidance for Development Plan Documents

The purpose of this section of the report is to provide guidance for preparing development plan documents dealing with allocations using the SFRA.

- ***Scope the Sustainability Appraisal of the Local Plan***
 - *Screen development options*
 - *Produce appropriate flood risk indicators*
- ***Avoid sites at high risk of flooding where no other planning objectives outweigh flood risk***
 - *Using Sustainability Appraisal and Site Assessment Spreadsheet.*
- ***Carry out the Sequential Test on proposed development sites***
 - *Using information provided in the SFRA and Site Assessment Spreadsheet to avoid sites at high risk.*
- ***Identify those sites where a greater understanding of flood risk is required***
 - *These should include key development sites at high risk of flooding.*
- ***Identify the likelihood of sites passing the Exception Test***
 - *Using the Sustainability Appraisal to assess development sites with regards to other planning objectives and assign weight given to flood risk as a planning constraint;*
 - *Using information provided in the SFRA to assess the level of risk to each site and likelihood of it remaining safe. If a site cannot pass all the criteria of the Exception Test it cannot be approved.*
- ***Allocate appropriate development through the Sustainability Appraisal***
 - *Produce evidence that both Tests have been applied by noting the outcome and decisions made to avoid, substitute or allocate the site.*
- ***Draft flood risk policies and develop guidance on each allocated site within the Sustainability Appraisal***
 - *Guidance should include the need for site-specific FRAs.*

1.1 Introduction

- 1.1.1.1 The SFRA provides the basis for the sequential approach. The LPA should consider flood risk, the mechanism of flooding as well as the spatial distributions and development vulnerability in all stages of the development planning process.
- 1.1.1.2 The SFRA promotes positive planning to deliver strategic opportunities that reduce flood risk to communities.

- 1.1.1.3 Throughout the risk-based sequential testing process, opportunities to minimise flood risk at each stage of the planning process need to be considered. The primary aim of these actions is to ensure that risks to people and property are effectively managed. The hierarchy of management decisions and actions comprise:
- Avoidance, by locating new development outside areas at risk of flooding;
 - Substitution, by changing from more vulnerable to less vulnerable land uses; and,
 - Control & Mitigation of residual risks, by implementing suitable flood risk management measures.
- 1.1.1.4 The SFRA provides information on flood risk allowing the LPA to:
- Produce appropriate policies for development management and site allocation;
 - Produce appropriate flood risk indicators that inform the Sustainability Appraisal;
 - Undertake the Sequential Test and (with sufficient and suitable information) Exceptions Testing; and,
 - Allocate appropriate land use for development.
- 1.1.1.5 It is recommended that a supporting document is prepared, by the LPA, recording decisions made for each proposed development site. This should include all evidence considered in making a decision and this record will form the evidence base that demonstrates that both the Sequential and Exception Test have been applied.
- 1.1.1.6 In granting planning permission it will be the requirement of Development Management officers to confirm that all parts of the Exception Test have been addressed. During the initial development plan stage, only the likelihood of passing the Exception Test can be assessed. To pass the Exception Test a site-specific FRA will be required to identify constraints and demonstrate that safe development is achievable.
- 1.1.1.7 The SFRA also provides information to allow planners to make strategic decisions that identify the amount and type of development that may be suitable in the community. It also summarises potential strategic mitigation strategies that may be required for development to be feasible in the area.

1.2 Sequential Test

- 1.2.1.1 When allocating or approving land for development in flood risk areas, those responsible for making development decisions are expected to demonstrate that there are no suitable alternative development sites located in lower flood risk areas.
- 1.2.1.2 The Sequential Test is the key driver for the SFRA. In order to carry out the Sequential Test the LPA need to know:
- Spatial extent of flood risk within the whole LPA area
 - Flood Zones
 - Flood Zone 1 – Low Probability: less than 0.1% AEP fluvial flood event
 - Flood Zone 2 – Medium Probability: between a 1% AEP and 0.1% AEP fluvial flood event
 - Flood Zone 3a – High Probability: with a 1% AEP or greater fluvial flood event
 - Flood Zone 3b – Functional Floodplain: land where water has to flow or be stored in times of flood. This is land which would flood with an annual probability of 1 in 20 (5% AEP) or greater in any year or is designed to flood in an extreme (0.1% AEP) flood.
 - Flood Zone 3ai – Land where water would flow in times of flood where it not prevented from doing so by infrastructure based on an annual probability of 1 in 20 (5% AEP) or greater.
 - Flooding from other sources

- Location of proposed development sites and the proposed vulnerability of that development in flood risk terms.

1.2.1.3 There are a number of steps that the LPA may follow when Sequentially Testing sites and assessing the likelihood that a site will pass the Exception Test. These are:

- The LPA is required to prioritise the allocation of land for development in ascending order from FZ 1 to FZ 3 (including subdivisions of FZ 3 into FZ 3a and FZ 3b);
- The general approach to be followed when assessing sites is included as Figure 1-A. This, combined with the information provided in the Site Assessment Spreadsheet, should be used to identify those sites to be avoided where risk is considered too great;
- Identify those sites where substitution is possible due to high percentage of land within lower flood risk areas;
- Produce a supporting document recording all decisions made during the decision-making process. Each proposed development site should be referenced and the decisions made to avoid, substitute, or allocate the site and the evidence and/or reasoning used to make the decision should be recorded.

1.2.1.4 There are a number of key challenges faced by the LPA in applying the Sequential Test. The Sequential Test is purely based on the Flood Zones, but these zones only take account of fluvial and tidal flooding, which ignore the presence of flood risk management measures such as defences. Other sources of flooding must also be considered in the spatial distribution of development such as surface water flooding, identified through the Updated Flood Map for Surface Water (UFMfSW). However, it can be problematic to map the spatial extent of flooding from other sources as well as matching the level of risk associated with other sources with those presented within the three Flood Zones. For instance, Flood Zone 3 cannot be directly related to a high susceptible area at risk of surface water flooding as the probability and consequences are significantly different.

1.2.1.5 Whilst it may not be appropriate to avoid development at risk from other sources of flooding, risk should be considered when taking a sequential approach to land use or the substitution of lower development vulnerability in higher risk areas within a development site.

1.3 Exception Test

1.3.1.1 If the Sequential Test has been successfully applied and the LPA cannot allocate development in lower flood risk areas, then the vulnerability of development should be considered.

1.3.1.2 **Only once the vulnerability of the development is defined should an assessment be made of whether or not that development is appropriate within that Flood Zone and whether the Exception Test needs to be applied.**

1.3.1.3 Where new development is exceptionally necessary within areas at risk of flooding, Government policy aims to make it safe without increasing flood risk elsewhere and where possible reducing overall flood risk.

1.3.1.4 Paragraph 102 of the NPPF states: "If, following application of the Sequential Test, it is not possible, consistent with wider sustainability objectives, for the development to be located in zones with a lower probability of flooding, the Exception Test can be applied if appropriate. For the Exception Test to be passed:

- it must be demonstrated that the development provides wider sustainability benefits to the community that outweigh flood risk, informed by a Strategic Flood Risk Assessment where one has been prepared; and
- a site-specific flood risk assessment must demonstrate that the development will be safe for its lifetime taking account of the vulnerability of its users, without increasing flood risk elsewhere, and, where possible, will reduce flood risk overall.

Both elements of the test will have to be passed for development to be allocated or permitted.

- 1.3.1.5 NPPF provides a good explanation as to what type of development the Exception Test needs to be applied. In some situations, for certain types of development, it is not appropriate to use the Exception Test to justify development. For example, highly vulnerable development cannot be justified within the high risk zone through the use of the Exception Test.

It will be the requirement of Development Management officers to make sure all parts of the Exception Test have been passed in granting planning permission. At a development plan stage, only the likelihood of passing the Exception Test can be assessed, as actually passing the Test will require the completion of a site-specific FRA to determine if the site and its occupiers will be safe during times of flood.

- 1.3.1.6 What should be done at this early stage of the planning process is to identify those sites in which the Exception Test is required and to avoid those sites in which flood risk is too great, using the information provided in the SFRA, or there are no overriding planning objectives for that development.

1.4 Applying the Sequential Test and assessing the likelihood of passing the Exception Test

- 1.4.1.1 This section provides the following guidance on how the LPA is to apply the Sequential and Exception Test within the Sustainability Appraisal of LDDs.

- 1.4.1.2 What the following guidance will do, if followed appropriately, is produce clear and transparent evidence that both the Sequential and Exception Test have been applied.

- 1.4.1.3 The guidance provided in this SFRA User Guide should be interpreted as a practicable approach in how the LPA should apply the Sequential and Exception Tests within the preparation of Local Plans.

1.4.2 Development Plan Flow Diagrams and Tables


- 1.4.2.1 The following flow diagrams and tables provide a recommended approach for the LPA in applying the two tests, keeping in mind the flood risk management hierarchy of avoid, substitute, control and mitigate, whilst identifying and allocating sustainable development sites.

- 1.4.2.2 Figure 1-2, illustrates the Sequential and Exception Tests as a process. The main inputs being the evidence provided in the SFRA and the LPA Core Strategy and Sustainability Appraisal. The flow diagram begins by the LPA assessing alternative development options at a strategic scale using the Sustainability Appraisal. This expands to use evidence provided in the SFRA to avoid inappropriate development sites, substitution within the site boundary and identifying those sites requiring Exception Testing. The flow diagram concludes by revisiting and updating the Sustainability Appraisal with the allocation of development sites.

- 1.4.2.3 During this process there is a need to identify which sites should be avoided or substituted, those which can go forward, or once the Sequential Test has been applied how to assess if the site will remain safe during the Exception Test. This is a step wise process and must be documented, but a challenging one as a number of the criteria used are qualitative and based on experienced judgement.


- 1.4.2.4 Figure 1-1 provides additional guidance on using the Site Assessment Spreadsheet produced in the SFRA. Figure 1-2 provides guidance on how to assess the likelihood of sites passing the Exception Test using key questions and evidence.

Figure 1-A: First and Second Pass of Proposed Development Sites Sequential Test



- 1.4.2.5 The LPA will need to assess the likelihood of sites passing the Exception Test. This is seen as a critical part of the spatial planning process by avoiding inappropriate development being allocated. The Environment Agency and / or Development Management are likely to object to inappropriate development.
- 1.4.2.6 By following the process outlined in Figure 1-1, the LPA should be able to obtain a greater understanding on the level of flood risk present at each key development site that remains following the application of the Sequential Test.
- 1.4.2.7 The LPA should use the Sustainability Appraisal process to assess alternative sites against flood risk indicators and other planning considerations before producing flood risk policies and development guidance.

Figure 1-B: Identifying the Likelihood of Passing the Exception Test



1.5 Flood Risk and other Land Use Policies

- 1.5.1.1 Flood risk is a material consideration in land use planning decision making and can greatly impact on the sustainability of various land uses in all locations. Having applied the Sequential Test and Exception Test where necessary, the resultant assessment of appropriateness and associated flood risk information will then influence the land use planning decision at whatever level it is being considered.
- 1.5.1.2 Land use policies and wider strategic decisions involving social and economic development in the LDDs will be influenced and shaped by the sequential approach informed by this SFRA.
- 1.5.1.3 For instance, Green Infrastructure (GI) is a planned and managed network of natural environmental components and green spaces that intersperse and connect the urban centres, suburbs and rural fringe consisting of:
- Open Spaces – parks, woodlands, nature reserves, lakes
 - Linkages – River corridors and canals, pathways and cycle routes and greenways
 - Networks of “urban green” – private gardens, street trees, verges and green roofs

- 1.5.1.4 With regards to flood risk, green spaces can be used to manage storm flows and free up water storage capacity in existing infrastructure to reduce risk of damage to urban property, particularly in city centres and vulnerable urban regeneration areas. GI can also improve accessibility to waterways and improve water quality, supporting regeneration and improving opportunity for leisure, economic activity and biodiversity.

GI should be incorporated into master planning and individual sites, directed by the need to retain exceedence flood paths and the natural attenuation of flood flows.

- 1.5.1.5 Areas identified as functional floodplain within the SFRA can act as river corridors which would provide an excellent linkage of GI and can provide flood storage during a flood event. Areas identified within the urban environment or upstream of Critical Drainage Areas (CDA) should be incorporated into GI strategies. Opening up land to create flow paths or flood storage areas can help protect current and future developments.

2 Guidance for Development Management

The aim of this Section is to provide guidance on the use of the SFRA by Development Management.

When reviewing individual planning applications, Planners should use the Guidance in this SFRA User Guide, NPPF and the Planning Practice Guidance to:

- ***Check whether the Sequential Test and/or the Exception Test have already been applied***
 - *Refer developer to Local Plan and supporting evidence to identify if the Sequential Test has been applied and development is likely to pass the Exception Test (a site may have already been assessed) ;*
 - *If evidence is available, the Sequential Test and likelihood of passing the Exception Test have been assessed. If no evidence is available, developers must carry out the Sequential and Exception Tests.*
- ***Refer developer to the following in order for them to apply the Sequential and Exception Tests***
 - *SFRA (to inform Sequential Test);*
 - *Site Assessment Spreadsheet (to compare similar sites already assessed);*
 - *SFRA (to inform Exception Test);*
 - *SFRA maps (to review scale and nature of flood risk and residual risk);*
- ***Consult with LLFA, Environment Agency and other relevant stakeholders to***
 - *Assess flood risk constraints identified on site using the SFRA*
- ***Scope an appropriate FRA***
 - *What is the scale and nature of risk from all sources?*
 - *Does the site lie within a CDA?*
 - *Are there any strategic mitigation requirements identified in the SFRA or Local Plan?*
- ***Consult with LLFA and Environment Agency over FRA acceptance/approval***
- ***Planners should always ensure that that they are viewing the most up-to-date information within the SFRA. Confirmation should be sought from the relevant local authority***

2.1 Introduction

- 2.1.1.1 The LPA are the decision-makers on planning applications for new development. Whilst it is the developer's responsibility to fully consider flood risk issues, the LPA should be involved during any pre-application discussions.
- 2.1.1.2 Following on from recommendations made in the Pitt Review, Development Management must take some of the roles and responsibilities from the Environment Agency as the first point of call in Flood Risk Management and planning applications.
- 2.1.1.3 Flood risk needs to be considered at a strategic level by Development Management officers, even though applications for proposed developments are submitted on a site by site basis. Applications may need to fit within a wider flood risk management strategy for an area rather than on a site by site basis.
- 2.1.1.4 Consideration of flood risk within the context of an individual planning application highlights flood risk that may be taken into account using information provided within the SFRA, as well as the guidance provided in NPPF and the EA's Standing Advice.
- 2.1.1.5 Development Management officers must always consider development from a strategic view point and the accumulative effect of all proposed development taking place, even though applications for developments are submitted at a site level. It should not be presumed that flood risk has been understood at a strategic high level and that one application may need to fit within a flood risk management strategy for an area.

2.2 The Sequential Test and Exception Test

- 2.2.1.1 Even if the proposed site is already identified as having been Sequentially Tested and having passed the Sequential Test, supported by the findings of the SFRA, (and transparent evidence that the Sequential Test has been passed) the developer must still apply the sequential approach to site layout when matching land use vulnerability.
- 2.2.1.2 However, where a site has not been identified as tested, then the Sequential Test will need to be applied i.e. the developer will need to provide evidence to the LPA that there are no other reasonable available sites where the development could be located. The LPA will then use this information to apply the Sequential Test. This particularly applies to Windfall Sites that have not been previously allocated.
- 2.2.1.3 Developers will need to provide evidence that the Exception Test can be passed. This will be needed for allocated sites and windfall sites, if required according to the vulnerability of the proposed land use, areas requiring redevelopment or regeneration, redevelopment of existing single properties or changes of use (changes of use only apply to caravan, camping, chalet sites or mobile home sites). Development Management will then need to review the evidence provided and decide whether a site passes the Exception Test.
- 2.2.1.4 Development in certain existing communities may find it difficult to pass both the Sequential Test and Exception Test due to the nature of flood risk and/or the scale of mitigation which would be required in order to make the development safe. In these instances, development applications should be refused and these areas should be transformed into flood risk policies by the LPA.

2.3 Supporting the FRA Process

- 2.3.1.1 All development applications must be supported by an appropriate site-specific FRA in accordance with the guidance provided in the NPPF and PPG.
- 2.3.1.2 At the earliest practical stage, Development Management should refer developers to the SFRA including the associated flood risk mapping. The developer should also be referred to the appropriate flood risk policies which could potentially influence their development proposals.
- 2.3.1.3 If a site has been identified as being at risk of flooding from any source, then it may be appropriate for Development Management and the developer to consult the Environment Agency, the LLFA and other relevant flood risk consultees, such as Yorkshire Water and the Canal and River Trust, to identify known flood-related site constraints and agree the scope of an FRA. However, the EA should only be consulted when identified as a statutory consultee in the planning process, where flood risk is from fluvial sources.
- 2.3.1.4 The Environment Agency Standing Advice should be used at this stage. This can be accessed online (<http://www.environment-agency.gov.uk/research/planning/82584.aspx>).
- 2.3.1.5 The Environment Agency is a statutory consultee for specific categories of development where flood risk is an issue. Table 2-1 outlines when a more detailed FRA may be required.

Table 2-1: FRA considerations and SFRA supporting evidence

Considerations	Supporting evidence in the SFRA
The development other than minor development is situated in Flood Zone 2 and 3	Flood Zone maps or Flood Map on Environment Agency website if updated. See Section 17 Para 046 of the Planning Practice Guidance for definition of minor developments
The development is situated in Flood Zone 1, but there are critical drainage problems (i.e. the development lies within a Critical Drainage Area) or the site has been identified as being at risk of flooding from other sources. (The requirement for an FRA in this instance is not set out in the SFRA but would need to be a local policy matter for it to be justified and should be discussed in more detail with Council planning officers)	Critical Drainage Area maps, Updated Flood Map for Surface Water maps, consult LLFA
The development is at risk of flooding from other sources of flooding	Updated Flood Map for Surface Water maps, Areas Susceptible to Ground Water Flooding map, consult LLFA where development exceeds 1 ha / 10+ properties, consult EA if within flood zones. LLFA databases on surface water flood incidents (if available)
The development is situated behind flood defences (possibility of overtopping during extreme flood event or breach)	Flood Risk Management maps, Flood Zone maps, climate change maps. Depth and hazard maps for both the 1 in 100 year and 1 in 1000 year flood events from FRM modelling studies where available
The development exceeds 1ha in size or 10+ properties	Consult Environment Agency (only where development site is located within flood zones 2 or 3). Consult LLFA on all major developments
Proposed works or structures, in, under, over or within 8 metres of the top of the bank of a	Consult Environment Agency

Considerations	Supporting evidence in the SFRA
<p>designated 'main river' may require a permit from the EA under the Environmental Permitting (England and Wales) Regulations 2010. This was formerly called a Flood Defence Consent. Some activities are also now excluded or exempt</p>	
<p>Any culverting operation or development which controls the flow of any Main River or stream. Ordinary Watercourses are now the responsibility of LLFAs and IDBs</p>	<p>Consult Environment Agency (main rivers), consult appropriate LLFA / IDB</p>

3 Guidance for Developers

The aim of this Section is to provide guidance to Developers on using the SFRA.

Developers should use the Guidance in this SFRA User Guide, NPPF and the Practice Guidance to:

- **Assess whether the site is a**
 - *Windfall development, allocated development (Note: for allocated sites, the Sequential Test is only not required if the application is for the development type that was sequentially tested at the allocations stage, or change of use to identify if Sequential and Exception Tests are required.*
- **Check whether the Sequential Test and/or the Exception Test have already been applied**
 - *Request information from the LPA on whether the Sequential Test or likelihood of the site passing the Exception Test have been assessed;*
 - *If not, provide evidence to the LPA that the site passes the Sequential Test and will pass the Exception Test.*
- **Consult with LPA Development Management, the Environment Agency and the wider group of flood risk consultees, where appropriate, to scope an appropriate FRA if required**
 - *Guidance on FRAs provided in this SFRA User Guide;*
 - *Also refer to Environment Agency Standing Advice, CIRIA Report C624, NPPF, Planning Practice Guidance;*
 - *Consult LPA emergency planners if required.*
- **Submit FRA to Development Management and Environment Agency for approval, where necessary**

3.1 Introduction

- 3.1.1.1 The SFRA provides the evidence base for developers to assess flood risk at a strategic level and determine the requirements of an appropriate site-specific FRA.
- 3.1.1.2 Developers will need to liaise closely with the LPA in the first instance to determine if a site is likely to pass the Sequential Test. If a site is considered suitable then developers should prepare a site-specific FRA.
- 3.1.1.3 Developers should consider all sources of flood risk when assessing the suitability of a site. Guidance on developing within Critical Drainage Areas (CDA) and areas at risk from sources other than fluvial flooding is provided in this section

3.2 The Sequential Test and Exception Test

3.2.1.1 The Sequential Test and Exception Test are fundamental in determining the suitability of land for development in regard to flood risk and avoidance of flood risk to new development. These tests may still be required at an individual site level. Table 3-1 identifies when the Sequential and Exception Tests are required for certain types of development and who is responsible for providing the evidence and those who need to apply the tests.

Table 3-1: Development types and application of Sequential and Exception Tests

Development	Sequential Test Required	Who Applies the Sequential Test?	Exception Test Required?	Who Applies the Exception Test?
Allocated Sites	No	LPA should have already carried out the test during the allocation of development sites	Dependent on land use vulnerability	LPA to advise on the likelihood of test being passed. But the developer must provide evidence that the test can be passed by providing planning justification and producing a detailed FRA
Windfall Sites	Yes	Developer provides evidence that the test can be passed to the LPA. The area to apply the Sequential Test across will be defined by local circumstances relating to the catchment area for the type of development proposed..	Dependent on land use vulnerability	Developer must provide evidence that the test can be passed by providing planning justification and producing a detailed FRA. Consult LLFA
Changes of Use	No, except for any proposal involving the change of use to caravan, camping or chalet site or to a mobile home or park home site	Developer provides evidence that the test can be passed to the LPA.	Dependent on land use vulnerability	Developer must provide evidence that the test can be passed by providing planning justification and producing a detailed FRA. Consult LLFA

3.3 Site specific Flood Risk Assessments

3.3.1.1 The principal aims of a FRA are to determine the level of flood risk to a site and to confirm that suitable flood management measures can be developed to control flooding, and safeguard life and property, without increasing risk to the surrounding area.

- 3.3.1.2 Once the site has been Sequentially Tested, and has been identified as being likely to pass the Exception Test, a site-specific FRA should be undertaken. The LPA and EA should be consulted in order to determine the content and scope of the FRA.
- 3.3.1.3 There are three levels of FRA:
- Level 1 is a screening study used to identify whether there are any flooding or surface water management issues that need to be considered further;
 - Level 2 is a scoping study that should be undertaken if the Level 1 FRA indicates that there are flood risk issues that need further consideration; and,
 - Level 3, which is a detailed study, where further quantitative analysis is required to fully assess flood issues and confirm that effective mitigation measures can be implemented to control flood risk.
- 3.3.1.4 The SFRA is an assessment of flood risk at a strategic level. This information can be used to provide evidence for Level 1 and Level 2 FRAs. Where a more detailed FRA is required, then a developer should undertake a detailed assessment of the flood risk at the site. The scope of the FRA should be agreed by the developer through consultation with the LPA and EA.
- 3.3.1.5 Where a more detailed FRA is required the developer should undertake a detailed assessment of the flood risk to the site, using the SFRA to appraise flood risk issues and referring to the guidance in this SFRA User Guide, NPPF, Planning Practice Guidance and CIRIA Report Development and Flood Risk. Developers should satisfy themselves that the data provided in this SFRA is up-to-date and accurate for use in their development proposals.
- 3.3.1.6 Table 3-2 indicates when a more detailed FRA is likely to be required. The actual scope of the FRA should be agreed between the developer, LPA and Environment Agency before it is undertaken.


Table 3-2: FRA considerations and SFRA supporting evidence

Considerations	Supporting evidence in the SFRA
The development other than minor development is situated in Flood Zone 2 and 3	Environment Agency Flood Map for Planning.
The development is situated in Flood Zone 1, but there are critical drainage problems (i.e. the development lies within a Critical Drainage Area) or the site has been identified as being at risk of flooding from other sources. (The requirement for an FRA in this instance is not set out in the SFRA but would need to be a local policy matter for it to be justified and should be discussed in more detail with Council planning officers)	Critical Drainage Area maps, Updated Flood Map for Surface Water maps, consult appropriate LLFA
The development is at risk of flooding from other sources of flooding	Updated Flood Map for Surface Water maps, Areas Susceptible to Ground Water Flooding map
The development is situated behind flood defences (possibility of overtopping during extreme flood event or breach)	Flood Risk Management maps, Flood Zone maps
The development exceeds 1 ha in size	Consult Environment Agency (only where development site is located within flood zones 2 or 3)
Proposed works or structures, in, under, over or within 8 metres of the top of the bank of a designated 'main river' may require a permit from the EA under the Environmental Permitting (England and Wales) Regulations 2010. This	Consult Environment Agency

Considerations	Supporting evidence in the SFRA
was formerly called a Flood Defence Consent. Some activities are also now excluded or exempt	
Any culverting operation or development which controls the flow of any Main River or stream. Ordinary Watercourses are now the responsibility of LLFAs and IDBs	Consult Environment Agency (main rivers), consult appropriate LLFA / IDB

- 3.3.1.7 The detail required for each level of FRA is highlighted in Figure 3-A. The production of a site-specific FRA can be seen as an iterative process with those carrying out a Level 1 FRA before moving on to a Level 2 and finally a Level 3. It is appropriate to review the level of risk present and assess whether development is appropriate and achievable at each stage of the assessment.
- 3.3.1.8 Significant consultation with the LLFA, LPA and EA may be required for complex development proposals. Complex developments may need to include flood mitigation measures and compensatory storage.
- 3.3.1.9 Figure 3-A also links the evidence provided in the SFRA which can inform the decision making process.

Figure 3-A: FRA Preparation



3.4 FRA Guidance

3.4.1.1 Flood Risk Assessments should follow the approach recommended by:

- The Environment Agency Standing Advice (<http://www.environment-agency.gov.uk/research/planning/82584.aspx>)
- CIRIA Report C624 Development and Flood Risk (Guidance for the Construction Industry) and;
- NPPF;
- Planning Practice Guidance

3.4.1.2 These documents describe when an FRA is required and the general issues that should be considered. The key requirements of a FRA are provided as a checklist in Section 26 Para 068 of the Planning Practice Guidance. In general, the FRA should address the following issues:

1. Development Description and Locations

- What is the type of development and where will it be located?

- What is the vulnerability classification of the current and future building use?
- Has the development site been assessed during the Level 1 and Level 2 SFRAs? (If so has the Sequential and Exceptions Testing been completed already?)

2. Definition of Flood Hazard

- What are the sources of flooding at the site?
- For each source how would flooding occur, referencing any historical records.
- What existing surface water drainage infrastructure is present on the site? (Consult with LPA, EA and Yorkshire Water)

3. Probability

- Confirm the FZ designation for the site (refer to the Flood Zone (FZ) maps)
- Determine the actual and residual risks at the site (refer to the FZ maps, depth and hazards maps (Level2 SFRA) and Flood Risk Management maps)
- What are the discharge rates and volumes generated by the existing site and proposed development?

4. Climate Change

- How is flood risk at the site likely to be affected by climate change?

5. Flood Risk Management Measures

- How will the site be protected from flooding, including the potential impacts of climate change, over the lifetime of the development?

6. Off Site Impacts

- How will the proposed development and measures be implemented to protect the site from flooding and control surface water run-off be designed and implemented?

7. Residual Risks

- What flood-related risks will remain after mitigation measures have been implemented?
- How, and by whom, will these risks be managed over the lifetime of the development?
- Is an emergency Flood Plan required?

8. Groundwater

- This mechanism of flooding should be considered particularly when determining the acceptability of SuDS schemes as a way of managing surface water drainage. Developers should consult with the LPA and EA at an early stage of the assessment.

9. Sewer systems

- Where the SFRA has identified a risk of surface water flooding, any water that escapes from the sewer system would tend to follow similar flow paths and pond in similar locations.
- Developers should take account of the guidance for development in CDAs. Where required, liaison with Yorkshire Water should be undertaken at an early stage in the assessment process to confirm localised sewer flooding problems that could affect the site.
- Future development should be designed so that it does not increase existing sewer flooding problems.

3.5 Critical Drainage Areas

In certain locations an increase in the rate of surface water runoff is known to make development susceptible to localised flooding. Insufficient capacity in the surface water drainage system may exacerbate localised flood risk in areas outside of the EA Flood Zones.

A detailed FRA would be expected for planned development within these areas regardless of Flood Zone designation. This should demonstrate that new development is not at risk of flooding from existing drainage systems, will not increase risk to adjacent development or land and will include appropriate mitigation measures to safely control surface water runoff.

Ideally, developers shall work closely with the LPA, LLFA, EA and Yorkshire Water to develop strategies that manage surface water runoff. Where Greenfield development is proposed, the aim should be to not increase runoff rates above the existing Greenfield rates. Where brownfield development is proposed then the EA actually seek a reduction in the overall runoff rate. Wherever possible, this should be achieved through the use of SuDS, constructed within the development site.

The effectiveness of a flow management scheme within a single site is limited by site constraints including (but not limited to) topography, geology (soil permeability), development density, adoption issues and available area. The design, construction and ongoing maintenance regime of such a scheme must be carefully defined at an early stage.

LPAs and LLFAs can designate CDAs as high flood risk areas.

3.6 Considering risk of flooding from other sources

3.6.1.1 Flood Risk Assessments (FRA) must take account of flood risk from all sources. The SFRA provides a more detailed analysis of actual and residual risk associated with flooding. At some locations there may be hydraulic interactions between different flooding sources. Where this is the case the FRA should look at the possible interactions in more detail. A FRA should reference any completed Surface Water Management Plan for guidance.

3.6.2 Canals

3.6.2.1 A FRA should consider the residual risk associated with canals overtopping and breaching. The developer should liaise with the LPA and Canal and River Trust to determine applicable emergency planning arrangements.

3.6.3 Considering the general risk of canal flooding

3.6.3.1 Developers should be aware that any site that is at or below canal water level may be subject to canal flooding. However, the canal water volume is finite and a FRA should be used to show in detail what residual risk could be associated with the canal. In its mitigation, building resilience into low level properties may apply or land may be raised.

3.6.4 Reservoirs

3.6.4.1 As part of a FRA, the developer should undertake a zone of search around their site to identify any reservoirs that lie on higher land. The risk of flooding from reservoirs should be considered in the FRA (which will be subject to the available data and national security implications of such an assessment).

- 3.6.4.2 Where this identifies smaller reservoirs, the FRA should determine the owner and maintenance regime of the reservoir. A more detailed investigation of the effects of the reservoir overtopping or failing should be undertaken. The developer should then liaise with the LPA and reservoir owner to determine applicable emergency planning requirements or mitigation needs. Where there is significant flood hazard identified to the site from such failure, and especially from unmaintained reservoirs, the developer should liaise closely with the LPA about the suitability of the site for development.

3.6.5 Drainage for new developments

- 3.6.5.1 Development has the potential to cause an increase in impermeable area, an associated increase in surface water runoff rates and volumes, and a consequent potential increase in downstream flood risk due to overloading of sewers, watercourses, culverts and other drainage infrastructure. The sewer network in many places across Yorkshire was designed to drain less development than that exists today. Development has added flow over time and the drainage network is known to be at capacity in many places.
- 3.6.5.2 Controlling surface water discharges from new development is a crucial consideration if flood risk to new and existing development downstream is to be effectively managed. Planned development can also play a role in reducing the number of properties that are directly at risk from surface water flooding. The Planning System has a key role to play in setting standards for sustainable drainage from new developments and ensuring that developments are designed to take account of the risk from surface water flooding. Full drainage design for new developments should be included at the application stage. Sustainable drainage plays an important part in reducing flows in the sewer network and in meeting environmental targets, alongside investment in maintenance and new capacity by Yorkshire Water. Yorkshire Water plan their investment on a five year rolling cycle, in consultation with key partners, including the LLFA and the Environment Agency. The LLFA should be consulted when considering drainage or mitigation options for new developments.

Sustainable drainage and the use of Sustainable Drainage Systems (SuDS) is supported by the policy direction in Future Water¹, Making Space for Water², the Pitt Review³ and the Flood and Water Management Act⁴ that provides for more sustainable management of the water cycle, working in partnership across different agencies and new responsibilities for local flood risk management. In particular, the Flood and Water Management Act requires developers where practicable, to include sustainable drainage in new developments to reduce flood risk and improve water quality.

The FWMA, 2010, transferred the adoption and maintenance of SuDS to Sustainable Drainage Systems Approval Bodies (SABs) established by local authorities, or LLFA's, under Schedule 3 of the Act. This designation of a SAB however has since been removed following lengthy consultation, with the announcement from the Department for Communities and Local Government (DCLG) in December 2014 that local planners will be responsible for delivering SuDS. Changes to planning legislation give provisions for major applications of ten or more residential units or equivalent commercial development to require sustainable drainage within the development proposals in accordance with the interim national standards published in April 2015.

The system proposed by government builds on the existing planning system, which developers and local authorities are already using. Policy changes to the planning system can also be introduced relatively quickly ensuring that flood risk benefits from sustainable drainage systems can be brought forward as part of planning application proposals.

The NPPF continues to reinforce how planning applications that fail to deliver SuDS above conventional drainage techniques could be rejected and sustainable drainage should form

1 Defra (2008) Future Water

2 Defra, Department for Transport, HM Treasury and Office of the Deputy Prime Minister (2005) Making Space for water: Taking forward a new Government strategy for flood and coastal erosion risk management in England; First Government response to the autumn 2004 Making space for water consultation exercise

3 The Pitt Review (2008) Learning lessons from the 2007 floods

4 Defra (2010) Flood and Water Management Act © Crown Copyright

part of integrated design secured by detailed planning conditions so that the SuDS to be constructed must be maintained to a minimum level of effectiveness. Maintenance options must clearly identify who will be responsible for SuDS maintenance and funding for maintenance should be fair for householders and premises occupiers; and, set out a minimum standard to which the sustainable drainage systems must be maintained.

3.6.5.3 Recognising the above, drainage from new developments should incorporate storage, with residual discharge of surface water to the following networks in order of preference:

- Infiltration drainage (e.g. SuDS - soakaways)
- Discharge to a watercourse
- Discharge to a public sewer

3.6.5.4 The choice of system will be determined by local ground conditions (including groundwater levels). Whilst infiltration SuDS may be the most suitable for new development, developers must consider the risk of contamination to underlying aquifers.

3.6.6 Development sites in the wider local authority districts

3.6.6.1 Developers should use the following guidance regarding surface water runoff from new developments:

Allowable discharge rates

- Development should aim for stricter runoff rates
- Development should deliver Greenfield runoff on Greenfield sites up to a 1 in 100 year storm event, considering climate change. Where volume cannot be controlled, Greenfield rates should be limited to a 1 in 1 year storm event
- Development should aim for a reduction in surface water runoff rates of at least 30% for Brownfield sites up to a 1 in 100 year storm event, considering climate change
- Development should be designed so that there is no flooding to the development in a 1 in 30 year event and so that there is no property flooding in a 1 in 100 year plus climate change event
- There may be local variations on this where outfalls are directly to larger watercourses and hence surface water discharges from development sites can pass downstream before the main peak on the watercourse.

3.6.6.2 Wherever possible, this should be achieved through the implementation of SuDS. Source control should be considered firstly. There may be opportunities to deliver SuDS through integrated solutions for collections of strategic sites. The future ownership and maintenance of SuDS systems should be discussed at the planning application stage with the relevant sections of the LPA (including Highways and Drainage), Yorkshire Water and the Environment Agency. More detail on SuDS is available in Appendix D.

3.6.6.3 The developer should liaise closely with the local authority drainage engineer, the Environment Agency and Yorkshire Water to determine appropriate discharge rates. The developer should prove that surface water discharges from the site will not have an adverse impact on flood risk elsewhere, with reference to investment planning by Yorkshire Water that may increase the capacity of the sewer network in the area.

Overland flow paths

3.6.6.4 Underground drainage systems have a finite capacity and regard should always be given to larger events when the capacity of the network will be exceeded. Hence there is a need to design for exceedance. This should be considered alongside any surface water flows likely to enter a development site from the surrounding area.

- 3.6.6.5 Master planning should ensure that existing overland flow paths are retained within the development. As a minimum the developer should investigate, as part of a FRA, the likely depths and extents of surface water flooding on a development site when the national Updated Flood Map for Surface Water (UFMfSW) indicates that there is a risk of surface water flooding. This is a precautionary, but an appropriate approach to reduce the risk of flooding to new developments. Green infrastructure should be used wherever possible to accommodate such flow paths. Floor levels should always be set a minimum of 300mm above adjacent roads to reduce the consequences of any localised flooding.
- 3.6.6.6 The effectiveness of a flow management scheme within a single site is heavily limited by site constraints including (but not limited to) topography, geology (soil permeability), development density, existing drainage networks within the site and surrounding area, adoption issues and available area. The design, construction and ongoing maintenance regime of such a scheme must be carefully defined at an early stage and a clear and comprehensive understanding of the catchment hydrological processes (i.e. nature and capacity of the existing drainage system) is essential.

3.6.7 Critical Drainage Areas

Certain locations are particularly sensitive to an increase in the rate and volume of surface water runoff from new development. There are generally known local flooding problems associated with these areas. These areas help to define the proposed Critical Drainage Areas (CDAs) in the SFRA. Specific drainage requirements are required in these areas to help reduce local flood risk. The SFRA has designated CDAs as high flood risk areas.

- 3.6.7.1 These are areas with complex surface water flooding problems that would benefit from a drainage strategy, which is most effectively carried out through a Surface Water Management Plan (SWMP).
- 3.6.7.2 The proposed CDAs, recommended in the SFRA, can be refined over time as more detailed information on flood risk and local flood management assets, including sewered catchments, becomes available.
- 3.6.7.3 In these areas, a detailed FRA is required regardless of which Flood Zone applies for all developments. This should demonstrate that new development is not at risk from flooding from existing drainage systems or potential overland flow routes. It should also demonstrate that the development will not adversely affect existing flooding conditions by the use of appropriate mitigation measures. The FRA should define and address the constraints that will govern the design of the drainage system and layout of the development site.
- 3.6.7.4 The Environment Agency Standing Advice allows developers to screen online for the level of flood risk assessment that is appropriate for a development with regard to the NPPF Flood Zones. This highlights the need for a FRA in Flood Zones 2 and 3 and in Flood Zone 1 where there are critical drainage problems. The Standing Advice notes that for developments in Flood Zone 1 FRA Guidance Note 1⁵ should be followed:
- 3.6.7.5 *'In areas where the Local Planning Authority has identified drainage problems through a Strategic Flood Risk Assessment or Surface Water Management Plan and they have indicated that a formal flood risk assessment is required'. FRA Guidance Note 1 requires FRAs to provide 'Proposals for surface water management that aims to not increase, and where practicable reduce the rate of runoff from the site as a result of the development (in accordance with sustainable drainage principles, and the Local Planning Authority's published SFRA).'*
- 3.6.7.6 Proposals for development in Critical Drainage Areas should follow the guidance and standards as set out below for developments that are within any Flood Zone.

Allowable discharge rates

⁵ Environment Agency. Flood Risk Assessment (FRA) Guidance Note 1, Development Greater Than 1 Hectare (ha) in Flood Zone 1 (and Critical Drainage areas less than 1ha) Can be accessed online at <http://www.environment-agency.gov.uk/static/documents/Research/FRAGuidanceNote1.pdf>

- 3.6.7.7 Development should seek to reduce existing local flooding problems and not add to them. The following guidance should be followed:
- Development should deliver Greenfield runoff on Greenfield sites up to a 1% AEP storm event, considering climate change. Where volume cannot be controlled, Greenfield rates should be limited to a 1 in 1 year storm event
 - Development should aim for a minimum reduction in surface water runoff rates of 50% for Brownfield sites, with an aim of reducing runoff to Greenfield rates up to a 1% AEP storm event, considering climate change
 - Development should be designed so that there is no flooding to the development in a 1 in 3.33 AEP event and so that there is no property flooding in a 1 in 100 year plus climate change event
- 3.6.7.8 Over time, it is envisaged that local authorities will commission drainage strategies (see below) to determine in more detail and establish the evidence base for set reductions in surface water runoff from development sites. With regard to this, the developer should liaise closely with the Environment Agency, Yorkshire Water and LPA as soon as possible to determine an appropriate reduction in runoff rate and volume with reference to discharge limits as laid down by any completed SWMP or Drainage Strategy for that area.
- 3.6.7.9 Wherever possible, this should be achieved through the implementation of SuDS. Source control should be considered firstly. There may be opportunities to deliver SuDS through integrated solutions for collections of strategic sites. The future ownership and maintenance of SuDS systems should be discussed at the planning application stage with the relevant sections of the LPA (including Highways and Drainage), Yorkshire Water and the Environment Agency. This approach should be taken unless the developer can demonstrate that this is not feasible and that there will be no adverse impact caused by the development elsewhere.

3.6.8 Integrated drainage

- 3.6.8.1 There is the potential for groups of development sites coming forward to share a central and integrated solution for managing surface water runoff. This is best investigated further through a SWMP or a Drainage Strategy. Such solutions can provide great benefits besides water management, including providing recreational facilities, improving biodiversity and making communities a better place to live. Where there are several sites that would share a communal facility, such sites may be funded through developer Section 106 or Community Infrastructure Levy payments. Drainage Strategies can be particularly useful for considering, recommending the implementation of and long term management arrangements for SuDS and setting appropriate runoff rates from new development.

4 Guidance for Flood Risk Management

4.1 Introduction

- 4.1.1.1 Throughout the risk-based sequential approach, opportunities should be taken to minimise flood risk at every stage of the planning process.
- 4.1.1.2 Mitigation measures should be seen as a last resort to address flood risk issues.
- 4.1.1.3 Mitigation measures must be designed to provide an appropriate level of protection to a site for the lifetime of the development. At many sites it may be technically feasible to mitigate or manage flood risk. However, the potential impacts of mitigation measures on flood risk to the surrounding community must be considered. Where the depth of flooding is substantial, these mitigation measures may result in practical constraints to development with significant financial implications.
- 4.1.1.4 The minimum acceptable standard of protection against flooding for new property within flood risk areas is the 1% AEP flood event for fluvial flooding, including allowance for climate change over the lifetime of the development.

4.2 Strategic Approach

- 4.2.1.1 Mitigation measures should be considered on a strategic basis to avoid a piecemeal approach and partnership is advocated between the LPA and EA. Measures should also be integrated with wider EA flood risk management works and strategies such as the CFMP.
- 4.2.1.2 Outline flood risk mitigation strategies should consider the wider, cumulative impacts of mitigation. This requires master-planning an area from a flood-risk perspective.
- 4.2.1.3 In summary, taking a strategic approach to flood risk management involves consideration of:
 - Avoidance of development in flood risk areas;
 - Implementing a sequential approach to site layout, substituting higher vulnerability development in lower flood risk areas;
 - Considering flooding from all sources;
 - Wherever possible, using open land or green infrastructure to reduce risk, (e.g. by providing compensatory flood storage);
 - Adopting mitigation measures that contribute to the wider community objectives for flood risk management in risk areas, (developers should aim to reduce risk to the wider community);
 - The design and use of SuDS; and,
 - Preparing emergency flood plans.

4.3 Potential mitigation measures

- 4.3.1.1 Mitigation measures should fit into the wider strategic FRM approach, that is advocated for a community and ensure that there is no increase in flood risk to the surrounding community. The developer should liaise closely with the Environment Agency and Development Management as to what mitigation measures may be suitable.
- 4.3.1.2 A summary of mitigation measures has been produced in Appendix E.

Appendices

A . Flood Risk Concepts

A.1 Introduction

Flooding is a natural process and can happen at any time in a wide variety of locations. It constitutes a temporary covering of land not normally covered by water and presents a risk when people, infrastructure and development and environmental assets are present in the area which floods. Assets at risk from flooding can include housing, transport and public service infrastructure, commercial and industrial enterprises, agricultural land and the environmental and cultural heritage.

Climate change predictions are that flood risk will increase due to more frequent severe storms bringing higher intensity rainfall and increasing run-off from land and buildings. This will cause rivers and streams to experience higher than normal flood flows and levels, and sewers and drains to surcharge more frequently than at present. The focus of activity in meeting these challenges in the future will be on flood risk management as opposed to simply providing flood defences. It is now widely recognised that whilst we cannot always prevent flooding we can manage the risks of it happening and reduce the consequences when flooding does happen.

As responsible authorities, the EA and LPAs, should embrace effective flood risk management issues and actions. The focus should aim to reduce flood risks through a variety of measures including:

- Through the planning process ensuring that vulnerable land uses are located away from high flood risk areas;
- Providing flood warning and emergency planning in flood risk areas;
- Raising awareness of flood risks amongst vulnerable communities;
- Constructing and maintaining appropriately designed surface water sewers and culverts;
- Using temporary and demountable flood defences and various flood prevention systems to buildings where appropriate;
- Constructing new flood defences where they are sustainable, and improving and maintaining those already existing; and
- Constructing weirs, sluices and other flood flow control and management structures.

Pro-active land use planning has a key role to play in flood risk management as it is one of the few activities that can result in the avoidance of flood risk as opposed to other activities that can only hope to reduce it. Effective flood risk management through the planning system is achieved through a hierarchy where:

- Avoidance of inappropriate development in high risk zones takes priority;
- Substitution of lower vulnerability uses when avoidance is not considered possible; and
- Mitigation if avoidance and substitution are not possible, then mitigation of risks using a variety of techniques may be considered.
- Flood risk assessment at all levels of planning and for all major developments is critical to inform decision-making by planners and developers.

A.2 Sources of Flooding

Flooding can occur from many different sources and may be experienced in isolation or as a combined flooding event. Different types and forms of flooding present a range of different risks. The associated hazards of speed of inundation, depth and duration of flooding can vary greatly.

With climate change, the frequency, pattern and severity of flooding are expected to change and become more damaging with time.

Major causes of flooding are:

- Coastal flooding is caused by higher sea levels than normal causing tidal water to overflow onto the land;
- Inland flooding is caused by prolonged and/or intense rainfall resulting in excess water flowing overland, ponding in natural hollows and low-lying areas or behind obstructions;
- River flooding occurs when the capacity of a watercourse is exceeded or a channel is blocked and excess water spills out from the channel onto adjacent low lying areas or floodplain;
- Flooding from artificial drainage systems occurs when flow entering a system, such as an urban storm water drainage system, exceeds its discharge capacity, it becomes blocked or it cannot discharge due to a high water level in the receiving watercourse;
- Groundwater flooding occurs when the level of water stored in the ground rises as a result of prolonged rainfall to ground level;
- Estuarial flooding may occur due to a combination of tidal and fluvial flows, with tidal levels being dominant in most cases; and
- A less frequent form of flooding arises from the failure of infrastructure designed to store or carry water (for example, the breach of a dam, a leaking canal or a burst water main), or to protect an area against flooding (e.g. breach of a flood defence, failure of a flap valve or pumping station or blockage of a pipe or culvert). Because of the sudden onset, the impacts of this form of flooding can be severe.

Historically the adopted approach in many SFRA has been not to consider other sources of flooding as a spatial or strategic issue. Through good design and attenuation of drainage inputs to sensitive watercourses, mitigation was the accepted way forward.

Increases in flooding impacting on people and property, due to development can be caused:

- Upstream by restricting the capacity and conveyance function of the watercourse and floodplain system;
- Downstream by decreasing the volume available for flood storage on the floodplain, altering flow routes on the floodplain or by changes to the channel which can increase the flow discharged to downstream locations; and
- By increasing runoff from reduced permeability surfaces, such as roads, roofs and car parks.

Fluvial Flooding

Flooding from watercourses is associated with the exceedance of channel capacity during higher flows. The process of flooding from watercourses depends on a number of catchment characteristics including; geographical location, variation in rainfall, steepness of the channel and surrounding floodplain and infiltration and rate of runoff (linked to land use i.e. degree of urbanisation). It is possible to generalise catchments into; large and relatively flat or small and steep, the two giving very different responses during large rainfall events.

The form of the floodplain, either natural or urbanised, can influence flooding from watercourses. The location of buildings and roads can significantly influence flood depths and velocities by altering flow directions and reducing the volume of storage within the

floodplain. Critical structures such as bridge and culverts can also significantly reduce capacity creating pinch points within the floodplain. These structures are also vulnerable to blockage by natural debris within the channel or by fly tipping and waste.

Surface Water Flooding

Flooding of land from surface water runoff is usually caused by intense rainfall that may only last a few hours and follows natural valley lines, creating flow paths along roads and through and around developments and ponding in low spots, which often coincide with fluvial floodplains in low lying areas. Hence any area at risk of fluvial flooding will almost certainly be at risk of surface water flooding.

Flooding in urban areas can also be attributed to sewers. Sewers are normally designed to a maximum of a 1 in 30 year design standard and hence sewer flooding problems will often be associated with more frequent storm events, when sewers can become blocked or fail. In the larger events that are less frequent but have a higher consequence, surface water will exceed the sewer system and flow across the surface of the land, often following the same flow paths and ponding in the same areas as overland flows.

Both 'Making Space for Water' and 'Future Water' recognise the importance of integrated urban drainage and the summer flooding of 2007 highlighted that surface water flooding can cause mass distress, damage and disruption. The Foresight Report (2004) estimated that 80,000 properties are at very high risk from surface water flooding (1 in 10 chance of occurring in any one year).

Groundwater Flooding

The occurrence of groundwater flooding is usually very local and unlike flooding from rivers and the sea, does not generally pose a significant risk to life due to the slow rate at which the water level rises. However, groundwater flooding can persist for a long period and cause significant damage to property, especial in urban areas, if not considered in development planning. In most cases groundwater flooding cannot easily be eliminated although the impact on buildings can be mitigated to some extent through various measures.

Flooding from Drainage Systems

Flooding from artificial drainage systems occurs when flow entering a system, such as an urban storm water drainage system, exceeds its discharge capacity, it becomes blocked or it cannot discharge due to a high water level in the receiving watercourse.

Foul sewers and surface water drainage systems are spread extensively across the urban areas with various interconnected systems discharging to treatment works and into local watercourses.

Typically foul systems will comprise a network of drainage sewers, sometimes with linked areas of separate and combined drainage, all discharging to sewage treatment works. Combined Sewer Overflows (CSOs) provide an overflow release from the drainage system into local watercourses or surface water systems during times of high flows.

Surface water systems will typically collect surface water drainage separately from the foul sewerage and discharge directly into watercourse.

A major cause of sewer flooding is often due to the connection of surface water drains to discharge into the combined sewer systems. Sewer capacity can then become an issue in large rainfall events causing the backing up of flood waters internally within properties or discharging through manholes.

Insufficient capacity can also become an issue where urban areas develop over time, with improved sewerage infrastructure provision not always provided to accommodate the additional flows.

English and Welsh water companies are required to maintain a register of flooding incidences due to hydraulic capacity problems on the sewage network. This database identifies properties where flooding has occurred on a frequency of 1 in 5 years and 1 in

10 years. The database is known as DG5 and DG10 registers. A register for 1 in 20 years is also recorded which includes properties under investigation.

Whilst this data can give an idea of those areas with limited drainage capacity, it must be acknowledged that it is a register of properties that have flooded due to the hydraulic inadequacies of the sewer systems, not properties at risk of flooding. Therefore it has limiting usefulness in predicting future flooding.

Data generated using hydraulic network models such as InfoWorks potentially provides a very useful tool with which to predict more widespread potential for sewer flooding and the use of such tools should be investigated during a Surface Water Management Plan.

Flooding from Reservoirs

Reservoirs can be a major source of flood risk, as experienced during the 2007 summer floods, where 18 reservoirs were affected across England. Whilst the probability of dam failure or breaching occurring is very small, the consequences of such an event can be devastating thereby presenting a risk of flooding which has to be considered.

Flooding from reservoirs is noted as an issue within the Pitt Review Recommendations and acknowledged by Hilary Benn, the then Secretary of State for Environment, Food and Rural Affairs. £1million has been pledged to improve reservoir safety specifically to produce inundation mapping for all reservoirs falling under the Reservoirs Act (i.e. those with a capacity of over 25,000 cubic metres).

Reservoirs are classified on a consequence of failure basis outlined below in Table A1 and it is now suggested that a better risk-based approach to reservoir safety is needed, focusing on those reservoirs that pose the greatest risk to the public, even if they are not currently covered by the Act.

Table A1: Reservoir Consequence Classification

Dam Category	Potential Consequence of Reservoir Failure
A	At least 10 lives at risk and extensive property damage
B	Fewer than 10 lives at risk or extensive property damage
C	Negligible risk to human life but some property damage
D	Negligible risk to human life and very limited property damage

The Environment Agency has produced simplified inundation maps for all reservoirs under the Reservoirs Act as required by Recommendation 57 of the Pitt Review. Trial projects were run in the North West to develop the specification for these maps and the Environment Agency produced maps for all reservoirs under the Act during 2009.

The Water Act 2003, which amended the Reservoirs Act 1975, requires all reservoir undertakers to prepare Flood Plans for those reservoirs where the dam failure could put people’s lives at risk or lead to major damage.

The reservoir Flood Plans will include:

- An inundation analysis to identify the extent and severity of flooding which could result from an uncontrolled release of water (i.e. breaching or failure)
- An on-site plan setting out what the undertaker would do in an emergency to try and to contain and limit the effects of the incident
- A communications plan with external organisations, mainly the emergency services

Defra’s ‘Guide to Emergency Planning for UK Reservoirs’, document helps reservoir owners to create appropriate Flood Plans.

Any allocations or applications for development immediately downstream of a reservoir should be considered carefully in liaison with the Environment Agency. It should be noted that the hazard is well managed through legislation and it is unlikely that the impact zone

downstream of a reservoir would be a reason to stop permitted development. It is likely that the flood risk would be mitigated through emergency planning.

Flooding from Canals

Canals are artificial navigable watercourses, many of which date back to the 18th century. In many places they are embanked and raised above the surrounding land. Locks on canals help boat traffic to pass up and down slopes. Canals are fed from reservoirs and watercourses and have overflow structures that pass water out of the canal when levels are high to lower level watercourses. Many of the inflow and outflow structures on canals are over 200 years old when they were designed to a 'rule of thumb'.

Flooding from canals can be caused by a variety of circumstances:

- Excess water can enter canals during times of high flows in feeder watercourses
- Reservoir failure could divert excess water into a canal
- Canals can intercept surface water running off from higher ground
- Surface water or excess water in a culverted watercourse that crosses under a canal can build up behind an embanked section of canal, which then causes the canal to fail or excess water to enter a canal
- The clay lining of a canal could fail, resulting in failure of an embanked section, dependent on local geology – relatively permeable materials such as sand are more prone to failure than impermeable clay.

In the event that a canal does fail, the height that the canal is elevated above surrounding land will affect to some degree the amount of flood hazard that could be caused by deep or fast flowing debris laden water, alongside the cause of failure (there will be a greater volume of water from failures caused by water building up behind an embankment). The amount of water that can escape depends on the pound length, which is the distance between two locks because the maximum volume of water that will outflow will be contained between the two locks or time taken for an operator to react to a failure to prevent further escape. The risk of flooding from canals is reduced by regular inspection by Canal and River Trust or others to identify any problems with inflow and outflow structures, canal lining or embankments.

Defence Failure

The condition of existing flood defences is an important consideration for local authority planners when allocating new development. NPPF considers that defended areas (i.e. those areas that are protected to some degree against flooding by the presence of a formalised flood defence) are still at risk of flooding, and therefore sites within these areas must be assessed with respect to the adequacy of the defences.

The condition of existing defences is assessed in the form of a 'rating' (1 to 5), and is a reflection of any signs of 'obvious' structural problems. The condition rating is determined on the basis of visual inspection, focussing on obvious signs of structural defect (e.g. slippage, cracking, poor maintenance), designed to inform the maintenance programme. The Environment Agency's Asset Information Management System (AIMS) supersedes the National Flood and Coastal Defence Database (NFCDD). The AIMS condition ratings are shown in Table A2.

Table A2: AIMS Condition Ratings for Flood Defences

Condition Rating	Condition	Condition Description
1	Very Good	Fully serviceable.
2	Good	Minor defects.
3	Fair	Some cause for concern. Requires careful monitoring.
4	Poor	Structurally unsound now or in the future.
5	Very Poor	Completely failed and derelict.

The condition of existing flood defences and whether they will continue to be maintained and/or improved in the future, is an issue that needs to be considered as part of the risk based sequential approach and in light of this, whether proposed land allocations are appropriate and sustainable. In addition, detailed FRAs will need to explore the condition of defences thoroughly, especially where these defences are informal and contain a wide variation of condition grades.

Defences that are not in good condition could be prone to failure during a flood event. Defences that offer a low standard of protection are likely to overtop during flood events that are more extreme than the event that they were designed to protect against. Flood risk associated with defence infrastructure is residual; however, the risks can be significant due to sudden onset and velocities reached by flood waters should a defence overtop or fail.

Flood Warning

The Environment Agency has the lead role in providing flood warnings in England and Wales. The aim of the flood warning service is to reduce risk to life, distress to people and damage to property caused by flooding by providing accurate, timely flood warnings to residents within the floodplain of rivers, estuaries and coasts; to the media and partner organisations.

It is crucial that people at risk receive appropriate flood warnings and take action to protect themselves and their property. Within the Environment Agency corporate plan “Creating a Better Place⁶” the Agency has highlighted three main targets:

- To have 80% of properties at risk in the floodplain in England and Wales receiving an appropriate flood warning service
- 75% of people who live in flood risk areas take appropriate action by 2011
- To have major incident plans in place for high flood risk areas.

⁶ Environment Agency (2006) Creating a Better Place: Corporate Strategy 2006-2011

Flood Warning Codes include⁷:

	Status
	Severe Flood Warning Severe flooding. Danger to life.
	Flood Warning Flooding is expected. Immediate action required
	Flood Alert Flooding is possible. Be prepared.
	Warning no longer in force Flood warnings and flood alerts that have been removed in the last 24 hours

The flood warnings are used to reduce the overall impact of flooding of people and property by lowering the vulnerability of the receptor. This is done by providing a warning which can then be used to remove people at risk or to relocate valuable possessions to higher levels.

Overview

Flooding in urban areas can come from a variety of sources and when flooding occurs it is often not clear where the water has come from. The Flood and Water Management Act defines local flood risk, for which local authorities will have a local leadership role, as the risk of flooding from ordinary watercourses (smaller watercourses that are not under the jurisdiction of the Environment Agency), surface water and groundwater.

Prior to the major flood events in summer 2007, the understanding of non Main River flooding was based on anecdotal evidence or described within Critical Ordinary Watercourse (COW) investigations undertaken by the Environment Agency. Little data could be abstracted from the water companies on sensitive drainage catchments where runoff impacts of new development could be significant on combined sewer systems. However, a significant proportion of recent flood insurance claims are due to flooding from non Main River sources, so this issue will become larger with a more energised climate.

Historically the adopted approach in many SFRAs has been not to consider other sources of flooding as a spatial or strategic issue.

Summer 2007 provided a stark reminder that the significance of capacity exceedance of artificial and natural drainage systems can be severe for many communities. Therefore a clear example was provided that flooding from all sources should be scoped into a SFRA and they should be taken into account through the planning system, and that new methods of rapid screening of these risks are required. On the back of the Pitt review, the Environment Agency prepared the national map showing areas susceptible to surface water flooding. This was developed by JBA from research for the Making Space for Water programme. JBA has since developed the 2nd generation Flood Map for Surface Water in 2010 and the most recent 3rd generation Updated Flood Map for Surface Water in 2013.

⁷ <http://www.environment-agency.gov.uk/homeandleisure/floods/31618.aspx>


Development can increase flood risk elsewhere in the following ways:

- Upstream by restricting the capacity and conveyance function of the watercourse and floodplain system
- Downstream by decreasing the volume available for flood storage on the floodplain, altering flow routes on the floodplain or by changes to the channel which can increase the flow discharged to downstream locations
- By increasing run-off from reduced permeability surfaces, such as roads, roofs and car parks

A.3 Flooding Likelihood & Consequence

Flood risk is generally accepted to be a combination of the likelihood of flooding and the potential consequences arising. It is assessed using the source – pathway – receptor model as shown in Figure A-2 below. This is a standard environmental risk model common to many hazards and should be the starting point of any FRA. However, it should be remembered that flood risk can come from many different sources and pathways and not simply those shown in the simplified form below.

Figure A-2 (Source-Pathway-Receptor model)



The principal sources of flooding are rainfall or higher than normal sea and river levels, the principal pathways are rivers, drains, sewers, overland flow and river and coastal floodplains and their defence assets. The receptors may include people, their property and the environment. All three elements must be present for flood risk to arise. Mitigation measures have little or no effect on sources of flooding but they can block or impede pathways or remove receptors.

The planning process is primarily concerned with the location of receptors, taking appropriate account of potential sources and pathways that might put those receptors at risk.

It is important to define the components of flood risk in order to apply this guidance in a consistent manner.

Likelihood

Likelihood of flooding is normally expressed as a percentage probability based on the average frequency measured or extrapolated from records over a large number of years. A 1% probability indicates the flood level that is expected to be exceeded on average once in 100 years, i.e. it has a 1 in 100 chance of occurring in any one year.

Considered over the lifetime of development, such an apparently low frequency or rare flood has a significant probability of occurring.

Consequence

Consequences of flooding depend on the hazards caused by flooding (depth of water, speed of flow, rate of onset, duration, wave-action effects, water quality) and the vulnerability of receptors (type of development, nature, e.g. age and structure of the population, presence and reliability of mitigation measures etc).

Flood risk is then normally expressed in terms of the following relationship:

- Flood risk = Probability of flooding x Consequences of flooding

A.4 Flooding Impacts on Property, People & the Environment

Flooding has a wide range of social impacts which may be difficult to delineate as they are interconnected, cumulative and often not quantifiable.

In small urban or steep upland catchments which have a very rapid response to rainfall, or with flooding due to infrastructure failure, flood waters can rise very quickly and put life at risk. Even shallow water flowing at 2 m/s can knock children and many adults off their feet and vehicles can be moved by water of 300 mm depth. The risks rise if the flood water is carrying debris.

The impact on people as a result of the stress and trauma of being flooded, or even of being under the threat of flooding, can be immense. This also extends to whole communities. Long term impacts can arise due to chronic illnesses and stress. Flood water contaminated by sewage or other pollutants (e.g. chemicals stored in garages or commercial properties) is particularly likely to cause illnesses, either directly as a result of contact with the polluted flood water or indirectly as a result of sediments left behind.

The degree to which populations are at risk from flooding is, therefore, not solely dependent upon proximity to the source of the threat or the physical nature of the flooding. Social factors also play a significant role in determining risk. Although people may experience the same flood, in the same area, at the same time, their levels of suffering are likely to differ greatly as a result of basic social differences. These differences will affect vulnerability in a variety of ways including an individual's or a community's response to risk communication (flood warning) and physical and psychological recovery in the aftermath of a flood. How individuals and communities experience the impact will also vary depending on their awareness of the risk of flooding, preparedness for the flood event and the existence or lack of coping strategies.

Flood hazard is based on a multiplier of flood depth, flood velocity and a debris factor⁸ and is presented on the following scale:

Table A3: Flood Hazard ratings

Hazard to people	Hazard to people classification
No Hazard	
Very Low Hazard "Flood zone with shallow flowing water or deep standing water"	Caution
Danger for some "Danger: flood zone with deep or fast flowing water"	Includes children, the elderly and the infirm
Danger for most "Danger: flood zone with deep fast flowing water"	Includes the general public

⁸ Defra and Environment Agency (2006) The Flood Risks to People Methodology, Flood Risks to People Phase 2, FD2321 Technical Report 1, HR Wallingford et al. wrote the report for Defra/EA Flood and Coastal Defence R&D Programme, March 2006.

Hazard to people	Hazard to people classification
Danger for all "Extreme danger: flood zone with deep fast flowing water"	Includes the emergency services

Flooding Impacts on Property

Flooding can cause severe property damage. Flood water is likely to damage internal finishes, contents, electrical and other services and possibly cause structural damage. The physical effects can have significant long-term impacts, with reoccupation sometimes not being possible for over a year. The costs of flooding are increasing, partly due to increasing amounts of electrical and other sophisticated equipment within developments.

The damage flooding can cause to businesses and infrastructure, such as transport or utilities like electricity and water supply, can have significant detrimental impacts on local and regional economies. The long-term closure of businesses, for example, can lead to job losses and other economic impacts.

New development or regeneration in flood risk areas has its additional short and long-term costs. The need to build resistant and resilient properties could significantly increase overall costs of development, whilst ongoing maintenance and insurance increase future expenditure.

Flooding Impacts on the Environment

Environmental impacts can be significant and include soil erosion, bank erosion, landslips and damage to vegetation. There can also be detrimental impacts on habitats, flora and fauna and water quality caused by various pollutants carried by floodwater.

Conversely, flooding can have a beneficial role in natural habitats. Many wetland habitats are dependent on annual flooding for their sustainability and can contribute to the storing of flood waters to reduce flood risk elsewhere. It is important to recognise the value of maintenance or restoration of natural riparian zones such as grasslands which protect the soils from erosion and 'natural' meadows which can tolerate flood inundation. The use of Green Infrastructure throughout river corridors can also play a vital role in enhancing the river environment as well as safeguarding land from future development, protecting people and buildings from flooding and reducing flood risk downstream.

A natural floodplain can help accommodate climate change and improve the quality of rivers and associated wetlands to help achieve 'good ecological status' or 'good potential ecological status' by 2015 under the Water Framework Directive (WFD). Meeting WFD objectives involves not only ecosystems, water quality, drought and flood impact considerations but also physical characteristics and morphology of the river channel, floodplain and associated structures.

B . Stakeholder Engagement and Data Management

B.1 Introduction

The majority of data provided in the SFRA has been obtained through consultation with those stakeholders with specific interest in or knowledge of sources of flooding within the study area.

There are a number of key consultees to the planning process. Stakeholders and their involvement within the preparation of the SFRA are discussed in Table B1.

Table B1: Stakeholder Involvement

Stakeholder	Involvement
LPA / LLFA	<p>Kirklees, Calderdale and Wakefield Councils were the main stakeholders in the preparation of the SFRA. They focused the scope of the SFRA and provided the detail needed for its production.</p> <p>An initial SFRA inception meeting was held to discuss the requirements of the SFRA and to determine the main tasks that needed to be completed.</p> <p>There have been several progress updates outlining progress to date and further data requests.</p>
Environment Agency	<p>The Environment Agency is a statutory consultee for Local Plans, DPDs, Sustainability Appraisals and Strategic Environmental Assessments.</p> <p>They are also a statutory consultee for planning applications. With regards to the SFRA, the Environment Agency has discretionary powers under the Water Resources Act (1991) to manage flood risk and, as a result, hold the majority of flood risk data in the UK. The External Relations Team were contacted for FRM modelling study outputs and Geostore was used to download a number of relevant datasets.</p> <p>The Environment Agency was also one of the main consultees throughout the preparation of the SFRA and their comments and guidance have been included within report revisions.</p>
Yorkshire Water	<p>The main source of information requested from Yorkshire Water was DG5 records and their SIRS/WIRS datasets. Yorkshire Water did not make their data available for use in the SFRA however.</p> <p>The council should continue to liaise with Yorkshire Water in conjunction with the Environment Agency to explore how they can contribute to the understanding of flood risk now or in the future.</p>
Canal and River Trust	<p>The Canal and River Trust provided their Asset Database including historic canal breach and overtop locations.</p>

B.2 SFRA Data Management

The SFRA should be viewed as a 'living' document for use in the day-to-day process of planning and development. It is therefore important that datasets collected for the SFRA are transparent and accessible. A Data Register has been produced and supplied to the individual Councils listing all data received throughout the SFRA process.

All data was reviewed on receipt and its quality assessed through professional judgement.

Most data requested was of the quality expected. Whilst the majority of the datasets could be mapped geographically using Geographic Information Systems (GIS), helping to visualise the risk of flooding, others were not. Historical flooding information was provided in both GIS format and through discussion with Council drainage engineers.

The Data Register will allow intended users of the SFRA to review the datasets used and for a central group to manage and update datasets when needed. The Data Register also states the name and organisation of who the data was supplied by. The names and organisations listed in the Data Register should be the first point of contact for any update to the SFRA to make sure the most up-to-date datasets are used.

B.3 Supplying SFRA Data

Whilst all data collected and produced during the SFRA process has been supplied to each LPA (report, maps, GIS data, Development Assessment Spreadsheet, data register) there should be controls on its use. It is anticipated that the SFRA report and associated maps will be published as GeoPDFs, and made available for download, on the Councils' websites, acting as the central source of SFRA data.

The use of much of the SFRA data will fall under the license agreement between the LPA and the Environment Agency as it has been produced using Environment Agency data.

The SFRA data should not be passed on to any third parties outside of the LPA. Any third party wishing to use existing Environment Agency flood risk datasets should contact the External Relations department in the Environment Agency. A charge is likely to apply for the use of this data.

C . Flood Risk Vulnerability Classification

Flood risk vulnerability classifications provide recognition that not all land uses have the same vulnerability to flooding. Some land uses such as residential developments are more vulnerable to the potential loss of life and damage to personal property and possessions than shops and offices for example. Five flood risk vulnerability classifications are contained in NPPF and the Planning Practice Guidance and these include:

- Essential infrastructure
- Highly vulnerable
- More vulnerable
- Less vulnerable
- Water compatible development

Flood Zone 1 – Low Probability

From a flood risk perspective all land uses are acceptable within Flood Zone 1. Flood risk is not considered to be a significant constraint to development and all land uses, included in the vulnerability classifications listed above are appropriate in this zone

A Screening Study will be required for development in this zone. This will determine whether further assessment of flood risk is required. This will take account of historical flood records of localised flooding, site specific considerations and the surface water proposals for the development, including mitigation.

However, due to potential impact on local flood risk, a full FRA will be required for all developments greater than 1ha in size. This will include further consideration of surface water drainage and onsite mitigation measures that may be required, particularly where the capacity of the surface water sewer or receiving watercourse is limited. This assessment will be undertaken by the developer of the site and should be appropriate to the scale, nature and location of the development. The Council’s Drainage Engineers and the EA will be able to advise potential developers as to their specific requirements on a site by site basis.

Flood Zone 2 – Medium Probability

Subject to the application of the Sequential Flood Risk Test, suitable types of development in Flood Zone 2 include:

- Essential infrastructure
- More vulnerable
- Less vulnerable
- Water compatible development.

Highly vulnerable uses should only be permitted in this zone if the Exception Test is passed. The SFRA is unable to assess whether the site will pass parts a. and b. of the Exception Test. However, the Council must be able to demonstrate the need for development through the spatial planning process.

An FRA will be required for all development in this zone. The FRA will need to assess the current level of flood risk as well as the level of flood risk following development. Development plans for the site will need to demonstrate that flood risk can be effectively and safely managed without increasing flood risk elsewhere.

Proposals will also need to demonstrate that access and egress to the development can be maintained during an extreme flood event and that development is set at an appropriate level. A further level of analysis, such as a breach / overtopping scenario assessment, may be required where development is planned behind or adjacent to existing defences in order to test the sustainability and robustness of the mitigation measures. In keeping with Flood Zone 1, other flood risk constraints, such as incidents of

localised flooding and other site-specific considerations will need to be addressed. Again, detailed FRAs will be undertaken by the developer of the site and the EA will be able to advise potential developers as to their specific requirements on a site by site basis.

Flood Zone 3 – High Probability

A Sequential Flood Risk Test is used to prioritise sites in order of vulnerability to flood risk and their acceptability for development. Developers should primarily focus on lower Flood Zones in preference to Flood Zone 3. Any proposals for development within Flood Zone 3 will require developers to undertake a detailed FRA. It should be noted that constraints to development are likely to be significant and developers should seek advice from the Council and the EA as to the specific requirements for assessment.

Flood Zone 3 is subdivided into Zones 3a, 3b and, for this SFRA, 3ai. Flood Zone 3b is the portion of floodplain that provides natural and/or managed attenuation and is considered to be functional floodplain. NPPF describes Zone 3b as land where water has to flow or be stored in times of flood. Flood Zone 3b should be identified as part of the SFRA. Flood Zone 3ai is an optional, indicative layer of information that is not included within the NPPF.

Zone 3a is potentially suitable for water compatible and less vulnerable land uses. The more vulnerable and essential infrastructure uses should only be permitted in this zone if the Exception Test is passed. Highly vulnerable development should not be permitted in this zone.

In Zone 3b, only essential infrastructure (subject to Exception Testing) and water compatible uses may be permitted. Where sites are partially located within Flood Zone 3b, it is recommended that the Council should avoid development by specifying water compatible uses or preferably public open space for these areas.

Flood Zone 3ai includes developed land within Flood Zone 3b where water would flow or be stored in times of flooding if not already constrained by development. Identification of zone 3ai allows the councils to assess risk within 3a in more detail showing areas where existing development is likely to be restricting flood flows and water storage that would otherwise be within the functional floodplain.

Should sites in Flood Zone 3ai become available for new or further development (e.g. as brownfield sites) then both the risk at the sites and their role in managing flood risk in the surrounding area should be carefully considered with no increase in development footprint. Flood Zone 3ai includes the areas of land that would be in Flood Zone 3b if not already developed and should therefore be used as an indicator of flood risk, from a modelled 1 in 20/25 year event, to existing developed sites'.

D . Sustainable Drainage Systems

D.1 Assessment of the Application of SuDS

Sustainable Drainage Systems (SuDS) are management practices which enable surface water to be drained in a more sustainable manner.

For Greenfield developments, the aim is to not increase runoff from the undeveloped situation; for Brownfield re-developments, the aim is to reduce existing runoff rates. Wherever possible, this should be achieved through the implementation of a sustainable drainage or flow retention systems, constructed within the boundaries of the development site.


There are many different SuDS techniques. As a result, there is no one correct drainage solution for a site. In most cases, a combination of techniques, using the Management Train principle, will be required. Figure D1 shows the SuDS Management Train principle where source control is the primary aim.

Just as in a natural catchment, drainage techniques can be used in series to change the flow and quality characteristics of the runoff in stages. The management train starts with **prevention**, for individual premises, and progresses through local **source controls** to larger downstream **site and regional controls**. Runoff need not pass through all the stages in the management train. It could flow straight to a site control, but as a general principle it is better to deal with runoff locally, returning the water to the natural drainage system as near to the source as possible. Only if the water cannot be managed on site should it be conveyed elsewhere. This may be due to the water requiring additional treatment before disposal or the quantities of runoff generated being greater than the capacity of the natural drainage system at that point. Excess flows would therefore need to be routed off site.

The design of SuDS will require active decisions between different options, often depending on the risks associated with each course of action. The risks of an area flooding have to be balanced with the costs of protecting the area from different levels of floods.

The management train concept promotes division of the area to be drained into **sub-catchments** with different drainage characteristics and land uses, each with its own drainage strategy. Dealing with the water locally not only reduces the quantity that has to be managed at any one point, but also reduces the need for conveying the water off the site.

Figure D-2 SuDS Management Train Principle⁹



⁹ CIRIA (2008) Sustainable Drainage Systems: promoting good practice – a CIRIA initiative

SuDS can reduce the amount and rate of runoff by a combination of infiltration, storage, and conveyance through a number of SuDS techniques. Their suitability however, relies on site conditions such as permeability and ground water levels, as summarised in Table D1.

Table D1: Suitability of SuDS Techniques

SuDS Technique	Infiltration	Storage	Conveyance
Green Roofs	x	✓	✓
Permeable Paving	✓	x	✓
Rainwater Harvesting	x	✓	x
Swales	✓	✓	✓
Detention Basins	✓	✓	✓
Ponds	x	✓	✓
Wetlands	x	✓	✓

Local Planning Authorities should:

- Promote the use of SuDS for the management of run-off
- Ensure their policies and decisions on development applications support and complement the Building Regulations on sustainable rainwater drainage, giving priority to infiltration followed by discharge to watercourses and lastly discharge to sewers
- Adopt policies for incorporating SuDS requirements in the Local Plan and Local Development Documents
- Encourage developers to utilise SuDS wherever practicable, if necessary through the use of appropriate planning conditions
- Develop joint strategies with sewerage undertakers and the Environment Agency to further encourage the use of SuDS

D.2 SuDS Guidance

For further information on the design of SuDS see CIRIA publications (www.ciria.org):

- Interim Standards for Sustainable Drainage Systems (March 2015):
- https://www.gov.uk/government/uploads/system/uploads/attachment_data/file/415773/sustainable-drainage-technical-standards.pdf
- Planning Practice Guidance:
<http://planningguidance.planningportal.gov.uk/blog/guidance/flood-risk-and-coastal-change/reducing-the-causes-and-impacts-of-flooding/why-are-sustainable-drainage-systems-important/>
- C521 : SuDS design manual for Scotland and N. Ireland (2000)
- C522 : SuDS design manual for England and Wales (2000)
- C523 : SuDS - best practice Manual (2001)
- C582 : SuDS - Source control using constructed pervious surfaces (2002)
- C609 : SuDS - hydraulic, structural and water quality advice (2004)
- C625 : Model Agreements for SuDS (2004)
- C697 : The SuDS Manual (2007)
- C698 : Site Handbook for the Construction of SuDS (2007)

D.3 Drainage for new developments

Development has the potential to cause an increase in impermeable area, an associated increase in surface water runoff rates and volumes, and a consequent potential increase in downstream flood risk due to overloading of sewers, watercourses, culverts and other drainage infrastructure. New development has added flow over time and drainage networks are known to be at capacity in many places.

Controlling surface water discharges from new development is a crucial consideration if flood risk to new and existing development is to be effectively managed. Planned development can also play a role in reducing the number of properties that are directly at risk from surface water flooding. The Planning System has a key role to play in setting standards for sustainable drainage from new developments and ensuring that developments are designed to take account of risk from surface water flooding. Sustainable drainage plays an important part in reducing flows in the sewer network and in meeting environmental targets; alongside investment in maintenance and new capacity by Yorkshire Water. Yorkshire Water plan their investment on a five year rolling cycle, in consultation with key partners, including the Environment Agency.

Wherever possible, this should be achieved through the implementation of SuDS. Source control should be considered firstly. There may be opportunities to deliver SuDS through integrated solutions for collections of strategic sites. The future ownership and maintenance of SuDS systems should be discussed at the planning application stage with the relevant sections of the LPA (including Highways and Drainage), Yorkshire Water and the Environment Agency.

The developer should liaise closely with the local authority drainage engineer, the Environment Agency and Yorkshire Water to determine appropriate discharge rates. The developer should prove that surface water discharges from the site will not have an adverse impact on flood risk elsewhere, with reference to investment planning by Yorkshire Water that may increase the capacity of the sewer network in the area.

The Council should make clear its approach to surface water management. All proposals for development must consider how surface water will be effectively controlled, and also propose SuDS techniques to fully attenuate surface water generated on the development site. The aim of this approach is to prevent any increase in surface water discharge to receiving watercourses or drainage infrastructure and prevent any increase in flood risk as a result of development.

The planning system has a key role to play in setting standards for SuDS from new developments and ensuring that developments are designed to take account of the risk from surface water flooding. Sustainable drainage and the use of SuDS is supported by the policy direction in Future Water¹⁰, Making Space for Water¹¹, the Pitt Review¹² and the Flood and Water Management Act¹³ that provides for more sustainable management of the water cycle, working in partnership across different agencies and new responsibilities for local flood risk management. In particular, the Flood and Water Management Act requires developers where practicable, to include sustainable drainage in new developments to reduce flood risk and improve water quality. It includes 'a requirement on developers to demonstrate that they have met national standards for the application of SuDS techniques before they can connect any residual surface water drainage to a public sewer (amending section 106 of the Water Industry Act 1991).'

The FWMA, 2010, transferred the adoption and maintenance of SuDS to Sustainable Drainage Systems Approval Bodies (SABs) established by local authorities, or LLFA's, under Schedule 3 of the Act. This designation of a SAB however has since been removed

¹⁰ Defra (2008) *Future Water*

¹¹ Defra, Department for Transport, HM Treasury and Office of the Deputy Prime Minister (2005) *Making Space for water: Taking forward a new Government strategy for flood and coastal erosion risk management in England; First Government response to the autumn 2004 Making space for water consultation exercise*

¹² The Pitt Review (2008) *Learning lessons from the 2007 floods*

¹³ Defra (2010) *Flood and Water Management Act* © Crown Copyright

following lengthy consultation, with the announcement from the Department for Communities and Local Government (DCLG) in December 2014 that local planners will be responsible for delivering SuDS. Changes to planning legislation give provisions for major applications of ten or more residential units or equivalent commercial development to require sustainable drainage within the development proposals in accordance with the interim national standards published in March 2015.

The system proposed by government builds on the existing planning system, which developers and local authorities are already using. Policy changes to the planning system can also be introduced relatively quickly ensuring that flood risk benefits from sustainable drainage systems can be brought forward as part of planning application proposals.

The NPPF continues to reinforce how planning applications that fail to deliver SuDS above conventional drainage techniques could be rejected and sustainable drainage should form part of integrated design secured by detailed planning conditions so that the SuDS to be constructed must be maintained to a minimum level of effectiveness. Maintenance options must clearly identify who will be responsible for SuDS maintenance and funding for maintenance should be fair for householders and premises occupiers; and, set out a minimum standard to which the sustainable drainage systems must be maintained.

Recognising the above, drainage from new developments should incorporate storage, with residual discharge of surface water to the following networks in order of preference:

- Infiltration drainage (e.g. SuDS - soakaways)
- Discharge to a watercourse
- Discharge to a public sewer

The choice of system will be determined by local ground conditions (including groundwater levels). Whilst infiltration SuDS may be the most suitable for new development, developers must consider the risk of contamination to underlying aquifers.

Local flood risk management will be an important responsibility for local authorities in the future, which includes managing the risk of flooding from surface water, groundwater and ordinary watercourses. Many of the localised flooding problems can be related to local watercourses that have been culverted as past development has taken place. The condition and standard of protection of these watercourses are unknown but they can be a significant source of flood risk. Flooding in the urban environment is difficult to separate into distinct sources and in reality surface water flooding will be from a combination of overland flows, sewers and highways gullies backing up and surcharging at manholes, local watercourses overtopping, culverts surcharging and potentially high groundwater levels. This is one reason why it is important for one body (the local authority) to take the lead in local FRM delivery.

D.4 Suitability of Sites for Infiltration/SuDS

The suitability of ground conditions including, for example, seasonal groundwater levels and soil permeability will need to be determined prior to development.

Sites assessed to be of low suitability will need to include sustainable solutions that do not depend on infiltration. Several SuDS storage alternatives may be suitable for sites where permeability is poor, and infiltration is not deemed appropriate. These include:

- Source control measures including rainwater recycling and drainage
- Filter strips and swales, which are vegetated features that hold and drain water downhill mimicking natural drainage patterns
- Basins and ponds to hold excess water after rain and allow controlled discharge that avoids flooding.

D.5 Critical Drainage Areas

Certain locations are particularly sensitive to an increase in the rate and volume of surface water runoff from new development. There are generally known local flooding problems

associated with these areas. These areas help to define the proposed Critical Drainage Areas (CDAs) in the SFRA. Specific drainage requirements are required in these areas to help reduce local flood risk. The SFRA has designated CDAs as high flood risk areas.

These are areas with complex surface water flooding problems that would benefit from a drainage strategy, which is most effectively done in a SWMP.

The proposed CDAs, recommended in the SFRA, should be designated as part of a Level 2 SFRA and refined over time as more detailed information on flood risk and local flood management assets, including sewer catchments, becomes available.

In these areas, a detailed FRA is required regardless of which Flood Zone applies to any development. This should demonstrate that new development is not at risk from flooding from existing drainage systems or potential overland flow routes. It should also demonstrate that the development will not adversely affect existing flooding conditions by the use of appropriate mitigation measures. The FRA should define and address the constraints that will govern the design of the drainage system and layout of the development site.

The Environment Agency Standing Advice allows developers to screen online for the level of flood risk assessment that is appropriate for a development with regard to the NPPF Flood Zones. This highlights the need for a FRA in Flood Zones 2 and 3 and in Flood Zone 1 where there are critical drainage problems. The Standing Advice notes that for developments in Flood Zone 1 FRA Guidance Note 1 should be followed:

'In areas where the Local Planning Authority has identified drainage problems through a Strategic Flood Risk Assessment or Surface Water Management Plan and they have indicated that a formal flood risk assessment is required'. FRA Guidance Note 1 requires FRAs to provide 'Proposals for surface water management that aims to not increase, and where practicable reduce the rate of runoff from the site as a result of the development (in accordance with sustainable drainage principles, and the Local Planning Authority's published SFRA).'

Proposals for development in Critical Drainage Areas should follow the guidance and standards as set out below for developments that are within any Flood Zone.

Development should seek to reduce existing local flooding problems and not add to them. The following guidance should be followed:

- Development should deliver Greenfield runoff on Greenfield sites up to a 1% AEP storm event, considering climate change
- Development should aim for a minimum reduction in surface water runoff rates of 50% for Brownfield sites, with an aim of reducing runoff to Greenfield rates up to a 1% AEP storm event, considering climate change
- Development should be designed so that there is no flooding to the development in a 1 in 3.33 AEP event and so that there is no property flooding in a 1 in 100 year plus climate change event

Over time, it is envisaged that local authorities will commission drainage strategies (see below) to determine in more detail and establish the evidence base for set reductions in surface water runoff from development sites. With regard to this, the developer should liaise closely with the Environment Agency, Yorkshire Water and LPA as soon as possible to determine an appropriate reduction in runoff rate and volume with reference to discharge limits as laid down by any completed SWMP or Drainage Strategy for that area.

Wherever possible, this should be achieved through the implementation of SuDS. Source control should be considered firstly. There may be opportunities to deliver SuDS through integrated solutions for collections of strategic sites. The future ownership and maintenance of SuDS systems should be discussed at the planning application stage with the relevant sections of the LPA (including Highways and Drainage), Yorkshire Water and the Environment Agency. This approach should be taken unless the developer can demonstrate that this is not feasible and that there will be no adverse impact caused by the development elsewhere.

E . Flood Risk Mitigation

E.1 Introduction

Throughout the risk-based sequential approach, opportunities should be taken to minimise flood risk at every stage of the planning process. Mitigation measures should be seen as a last resort to address flood risk issues.

Mitigation measures must be designed to provide an appropriate level of protection to a site for the lifetime of the development. At many sites it may be technically feasible to mitigate or manage flood risk. However, the potential impacts of mitigation measures on flood risk to the surrounding community must be considered. Where the depth of flooding is substantial, these mitigation measures may result in practical constraints to development with significant financial implications.

The minimum acceptable standard of protection against flooding for new property within flood risk areas is the 1% AEP flood event for fluvial flooding, including allowance for climate change over the lifetime of the development.

E.2 Strategic approach

Mitigation measures should be considered on a strategic basis to avoid a piecemeal approach and partnership is advocated between the LPA and EA. Measures should also be integrated with wider EA flood risk management works and strategies such as the CFMP.

Outline flood risk mitigation strategies should consider the wider, cumulative impacts of mitigation. This requires master-planning an area from a flood-risk perspective.

In summary, taking a strategic approach to flood risk management involves consideration of:

- Avoidance of development in flood risk areas;
- Implementing a sequential approach to site layout, substituting higher vulnerability development in lower flood risk areas;
- Considering flooding from all sources;
- Wherever possible, using open land or green infrastructure to reduce risk, (e.g. by providing compensatory flood storage);
- Adopting mitigation measures that contribute to the wider community objectives for flood risk management in risk areas, (developers should aim to reduce risk to the wider community);
- The design and use of SuDS; and,
- Preparing emergency flood plans.

E.3 EU Floods Directive & the Flood Risk Regulations

The European Flood Directive (2007) sets out the EU's approach to managing flood risk and aims to improve the management of the risk floods pose to human health, the environment, cultural heritage and economic activity.

The Directive was translated into English law by the Flood Risk Regulations (FRR) 2009 and outlines the requirement for the Environment Agency and Lead Local Flood Authorities (LLFA) to create Preliminary Flood Risk Assessments (PFRAs), with the aim of identifying significant Flood Risk Areas.

PFRAs should cover the entire area for local flood risk (focusing on ordinary watercourses, surface water and groundwater flooding). Where significant Flood Risk Areas are identified using a national approach (and locally reviewed), the LLFA are then required to undertake flood risk hazard mapping and Flood Risk Management Plans (FRMPs).

The FRMP will need to consider objectives for flood risk management (reducing the likelihood and consequences of flooding) and measures to achieve those objectives.

The Environment Agency have implemented one of the exceptions for creating PFRAs, etc for main rivers and coastal flooding, as they already have mapping (i.e. Flood Map) and plans (i.e. CFMPs) in place to deal with this. The Environment Agency have therefore focused their efforts on assisting LLFAs through this process.

E.4 Flood & Water Management Act 2010

The Flood and Water Management Act (FWMA)¹⁴ received Royal Assent on 8th April 2010. The Act creates unifying legislation covering all forms of flooding and shifting the emphasis from building defences to managing risk. The Act creates clearer roles and responsibilities and provides for a more risk-based approach. Local authorities have a new lead role in managing local flood risk (from surface water, ground water and ordinary watercourses) and a strategic overview role for all flood risk for the Environment Agency.

The Act aims to:

- Reduce the likelihood and impacts of flooding
- Improve the ability to manage the risk of flooding, by clarifying who is responsible for what
- Reduce pollution and improve water quality
- Give water companies better powers to conserve water during drought
- Reduce red tape and other burdens on water and sewerage companies
- Improve the overall efficiency of the industry.

The content and implications of the Act provide considerable opportunities for improved and integrated land use planning and flood risk management by local authorities and other key partners. The integration and synergy of strategies and plans at national, regional and local scales, is increasingly important to protect vulnerable communities and deliver sustainable re-generation and growth. Key areas of the Act have particular implications for local authorities, land use planning and related flood risk. These include:

- To give the Environment Agency an overview of all flood and coastal erosion risk management and unitary and county councils the lead in managing the risk of all local floods
- Local authorities will have an enhanced leadership role in local flood risk management which includes ensuring that flood risk from all sources, including from surface run-off, groundwater and ordinary watercourses, is identified, taken account of in the spatial planning process and managed as part of locally agreed work programmes
- Local authorities will develop a suite of measures for managing local flood risk, for example, surface water mapping, appropriate development planning and collating information on flood risk and drainage assets
- County and unitary authorities will be responsible for local flood risk assessment and lead in ensuring the production of SFRA and SWMPs
- SFRA will provide the evidence to allow LPAs to factor flood risk into their Local Plans, DPDs and individual planning proposals, and help to determine where SWMPs are needed
- County and unitary authorities will lead new local partnerships and have responsibility for adopting and maintaining sustainable drainage systems (SuDS) in new development, where they affect more than one property
- County or unitary authorities, the Environment Agency and IDBs will have powers to formally designate natural and man-made features (similar in principle to the Listed Buildings classification), which help to manage flood or coastal risk; they

¹⁴ <http://www.defra.gov.uk/publications/2012/12/14/pb13844-fmwa-progress/>

will give formal consent before anyone can change or remove the feature and use enforcement powers where needed

- To encourage the uptake of sustainable drainage systems by removing the automatic right to connect to sewers and providing for unitary and county councils to adopt SuDS for new developments and redevelopments
- Surface water connection to public sewers will be conditional on meeting new national standards for SuDS, and the approval of a SuDS approving body will be needed, and a certificate issued, before development can begin
- Increased emphasis is needed on enabling flood water to safely flow overland with green infrastructure and safe flow routes being identified as part of flood risk assessments
- All relevant authorities will have a duty to cooperate and share information
- Right to Connect (Water Industry Act, 1991) S106 of the act has been amended by the FWMA so that for new developments the approved sustainable drainage system must be constructed to connect to the public sewer network
- This will need to be approved to the new National SuDS Standards by the Lead Local Flood Authority
- Once constructed, the LLFA will adopt the system and becomes responsible for maintaining it.

E.5 Reducing flood risk through site layout and design

Flood risk should be considered at an early stage in deciding the layout and design of a site to provide an opportunity to reduce flood risk within the development.

A risk-based approach should be applied to try to locate more vulnerable land use to higher ground, while more flood-compatible development (e.g. vehicular parking, recreational space) can be located in higher risk areas.

Waterside areas, or areas along known flow routes, can be used for recreation, amenity and environmental purposes, allowing the preservation of flow routes and flood storage, whilst at the same time providing valuable social and environmental benefits contributing to other sustainability objectives. Landscaping should ensure safe access to higher ground from these areas, and avoid the creation of isolated islands as water levels rise.

Proposed works or structures, in, under, over or within 8 metres of the top of the bank of a designated 'main river' may require a permit from the EA under the Environmental Permitting (England and Wales) Regulations 2010. This was formerly called a Flood Defence Consent. Some activities are also now excluded or exempt. It is likely that the EA will require an unobstructed access and maintenance easement within these areas.

E.6 Modification of ground levels

Modifying ground levels to raise the land above the required flood level is an effective way of reducing flood risk to the site in question.

However, in most areas of fluvial flood risk, conveyance or flood storage may be reduced by raising land within the floodplain, adversely impacting on flood risk downstream. Compensatory flood storage must be provided, in general, on a level for level, volume for volume basis on land that does not currently flood but is adjacent to the floodplain. In general it should be in the vicinity of the site and within the red line of the planning application boundary (unless the site is strategically allocated).

Where a site is entirely within the floodplain it is not possible to provide onsite compensatory storage.

The need for compensatory storage must be discussed at the earliest stage of planning as this will be a major constraint as this requirement may have significant implications for the yields achieved for individual sites.

E.7 Local flood storage

Where development reduces the volume of floodplain storage it will be necessary to provide compensatory storage locally. This could be an environmental wetland area, designated washland (designed to flood) or a flood basin. This can also be considered within urban design if areas are designated to flood in a flood event (e.g. ground floor of a development with residential occupancy on first floor).

On a strategic catchment-wide scale, appropriately located flood storage basins and washlands can not only provide a reduction in flood risk, but can also enhance and contribute to wetland restoration and habitat creation as well as potentially increasing the recreational value of many river corridors. For upstream flood storage schemes to maximise benefits downstream, they need to be located in suitable areas of the catchment. Locating flood storage basins too high in the catchment could mean that a large proportion of a flood event is still able to travel downstream from other areas in the catchment.

The need for compensatory storage must be discussed at the earliest stage of planning as this will provide a major constraint on development. This requirement may have significant implications for the yields achieved for individual sites due to the associated land take this may require.

E.8 Raised defences

Construction of raised floodwalls or embankments to protect new development is not a preferred option, as a residual risk of flooding will remain. Compensatory storage must be provided where raised defences remove storage from the floodplain.

Temporary or demountable defences are not acceptable flood protection for new development.

E.9 Developer contributions to flood defences

In some cases, it may be necessary for the developer to make a contribution to the improvement of flood defence provision that would benefit both the development and the local community.

E.10 Building design

Raising of floor levels within a development avoids damage to the interior, furnishings and electrics in times of flood. If it has been agreed with the EA that, in a particular instance,

the raising of floor levels is acceptable, they should normally be raised to 600mm above the maximum water level during a 1% AEP event including allowance for climate change.

Making the ground floor of a building water-compatible (for example a garage or basement), is an effective way of raising living space above flood levels.

Constructing a building on stilts is not considered an acceptable means of flood mitigation for new development. However it may be allowed in special circumstances if it replaces an existing solid building, as it can improve flood flow routes. In these cases attention should always be paid to safe access and egress and legal protection should be given to ensure the ground floor use is not changed in the future.

E.11 Resistance and resilience

The 2007 document 'Improving the Flood Performance of New Buildings'¹⁵ provides further details on possible resistance and resilience measures.

E.12 Temporary barriers

Temporary barriers consist of moveable flood defences that can be fitted to doorways and windows. On a smaller scale it is likely that the EA will require an unobstructed access and maintenance easement within these areas, temporary snap-on covers for airbricks and air vents can also be fitted to prevent the entrance of flood water.

E.13 Permanent barriers

Permanent barriers can include built-up doorsteps, rendered brick walls and toughened glass barriers.

E.14 Wet-proofing

This involves designing interiors to reduce damage caused by flooding by, for example:

- Installing electrical circuitry at a higher level with power cables being carried down from the ceiling rather than up from the floor
- Using water-resistant materials for floors, walls and fixtures.

Resilience measures will be specific to the nature of the flood risk, and as such will be informed and determined by a FRA.

E.15 Making development safe

Safe access and egress

The developer must ensure that safe access and egress can be provided to an appropriate level for the type of development.

As part of a FRA, the developer should, with the EA, review the acceptability of the proposed access.

For the purpose of the SFRA it is considered appropriate to provide low hazard access and egress routes associated with new housing developments. Environment Agency guidance suggests that all development should have dry access and egress routes in the 1% AEP event and for the lifetime of the development which for residential is a minimum of 100 years. For residential sites, the upper end category of the February 2016 climate change allowances for the appropriate river basin district should be applied.

¹⁵ Communities and Local Government (2007) Improving the Flood Performance of New Buildings – Flood Resilient Construction

E.16 Making Space for Water

Opportunities for river restoration and enhancement

All new development close to rivers should consider the opportunity to improve and enhance the river environment. Developments should look at opportunities for river restoration and enhancement as part of the development. Options include backwaters, de-silting, in-channel habitat enhancement and removal of structures. When designed properly, such measures can have benefits such as reducing the costs of maintaining hard engineering structures, reducing flood risk, improving water quality and increasing biodiversity. Social benefits are also gained by increasing green space and access to the river.

Opportunities for floodplain restoration

It is an objective of NPPF to safeguard land from development that may be required for current or future flood management. In areas of high flood risk there may be a strong case for allowing previously developed sites to return to natural functional floodplain in urban areas where they can convey and store flood water reducing the risk of flooding to development.

Buffer strips

Developers should set back development from the landward toe of fluvial defences (or top of bank where defences do not exist) and this distance should be agreed with the EA. This provides a buffer strip to 'make space for water', and ensure access to defences is maintained.

E.17 Recommendations for surface water management

LLFAs should co-ordinate any future surface water management work. The Defra Surface Water Management Plan Guidance (2009) supports the use of SFRAs in providing the evidence base for where SWMPs are required.

Surface water management needs to take a holistic approach, taking into account all the sources of local flood risk, including from sewers, overland flow, culverted and open watercourses and groundwater. A suite of options are available for surface water management including source control, such as the implementation of SuDS, increasing the capacity of sewers, structures or watercourses, storing excess water and managing exceedance flows through urban design and "Green Infrastructure". SWMPs should provide the opportunity to undertake detailed sewer modelling and pool together the knowledge and understanding from different organisations to help assess options to reduce surface water flood risk to new and existing development.

Options to reduce flood risk in one location should not increase risk upstream or downstream. SWMP areas may cross one or more local authority area and several local authorities, the Environment Agency and Yorkshire Water can be brought together in a SWMP partnership to develop sustainable options to manage surface water flood risk.

There is the potential for groups of development sites coming forward to share a central and integrated solution for managing surface water runoff. This is best investigated further through a SWMP or a Drainage Strategy. Such solutions can provide great benefits besides water management, including providing recreational facilities, improving biodiversity and making communities a better place to live. Where there are several sites that would share a communal facility, such sites may be funded through developer Section 106 or Community Infrastructure Levy payments. Drainage Strategies can be particularly useful for considering, recommending the implementation of and long term management arrangements for SuDS and setting appropriate runoff rates from new development.